

SORTED BY ICAO CODE

ICAO	IATA	City	Country	Airport
BGSF	SFJ	Sondre Stromfjord	Greenland	Kangerlussuaq
BGTL	THU	Thule	Greenland	Thule AB
BIKF	KEF	Keflavik	Iceland	Keflavik
CYEG	YEG	Edmonton	Canada Alberta	Edmonton Intl
CYHZ	YHZ	Halifax	Canada Nova Scotia	Halifax Intl
CYJT	YJT	Stephenville	Canada Newfoundland	Stephenville
CYMX	YMX	Montreal (Mirabel)	Canada Quebec	Montreal Intl (Mirabel)
CYOW	YOW	Ottawa	Canada Ontario	Ottawa / MacDonald-Cartier Intl
CYQX	YQX	Gander	Canada Newfoundland	Gander Intl
CYRB	YRB	Resolute Bay	Canada North West Terr.	Resolute Bay
CYUL	YUL	Montreal (Dorval)	Canada Quebec	Montreal Intl (Dorval)
CYVR	YVR	Vancouver	Canada British Columbia	Vancouver Intl
CYWG	YWG	Winnipeg	Canada Manatoba	Winnipeg Intl
CYYC	YYC	Calgary	Canada Alberta	Calgary Intl
CYYQ	YYQ	Churchill	Canada Manatoba	Churchill
CYYR	YYR	Goose Bay	Canada Newfoundland	Goose
CYYT	YYT	Saint Johns	Canada Newfoundland	St. Johns Intl
CYYZ	YYZ	Toronto	Canada Ontario	Toronto / Pearson Intl
DGAA	ACC	Accra	Ghana	Kotoka Intl
DIAP	ABJ	Abidjan	Ivory Coast	Felix Ho'uphouet-Boigny
DNKN	KAN	Kano	Nigeria	Mallam Aminu Kano
DNMM	LOS	Lagos	Nigeria	Murtala Muhammed
DNPO	PHC	Port Harcourt	Nigeria	Port Harcourt
DXXX	LFW	Lome	Togo	Tokoin
EBBR	BRU	Brussels	Belgium	Brussels Natl
EBLG	LGG	Liege	Belgium	Liege
EBOS	OST	Ostend	Belgium	Ostend
EDDF	FRA	Frankfurt / Main	Germany	Frankfurt / Main
EDDH	HAM	Hamburg	Germany	Hamburg
EDDK	CGN	Cologne-Bonn	Germany	Cologne-Bonn
EDDL	DUS	Dusseldorf	Germany	Dusseldorf
EDDM	MUC	Munich	Germany	Munich
EDDS	STR	Stuttgart	Germany	Stuttgart
EDDV	HAJ	Hannover	Germany	Hannover
EDFH	HHN	Hahn	Germany	Hahn
EFHK	HEL	Helsinki	Finland	Vantaa
EFTU	TKU	Turku	Finland	Turku
EGAA	BFS	Belfast	United Kingdom	Aldergrove
EGBB	BHX	Birmingham	United Kingdom	Birmingham
EGCC	MAN	Manchester	United Kingdom	Manchester
EGKK	LGW	London-Gatwick	United Kingdom	Gatwick
EGLL	LHR	London-Heathrow	United Kingdom	Heathrow
EGPF	GLA	Glasgow	United Kingdom	Glasgow
EGPK	PIK	Prestwick	United Kingdom	Prestwick
EGSS	STN	London-Stansted	United Kingdom	Stansted
EHAM	AMS	Amsterdam	Netherlands	Schiphol
EHBK	MST	Maastricht	Netherlands	Maastricht-Aachen
EIDW	DUB	Dublin	Ireland	Dublin Intl
EINN	SNN	Shannon	Ireland	Shannon
EKBI	BLL	Billund	Denmark	Billund
EKCH	CPH	Copenhagen,	Denmark	Kastrup
ELLX	LUX	Luxembourg	Luxembourg	Luxembourg
ENBR	BGO	Bergen	Norway	Flesland
ENGM	GEN	Oslo	Norway	Gardermoen
ENZV	SVG	Stavanger	Norway	Sola
ESGG	GOT	Goteborg	Sweden	Landvetter
ESMS	MMX	Malmo	Sweden	Sturup
ESSA	ARN	Stockholm	Sweden	Arlanda
ETAR	RMS	Ramstein	Germany	Ramstein AB
FABL	BFN	Bloemfontein	South African Rep	Bloemfontein
FACT	CPT	Cape Town	South African Rep	Cape Town Intl

SORTED BY ICAO CODE

ICAO	IATA	City	Country	Airport
FADN	DUR	Durban	South African Rep	Durban Intl
FAJS	JNB	Johannesburg	South African Rep	Johannesburg Intl
FAMM	MBD	Mafikeng	South African Rep	Mafikeng Intl
FBSK	GBE	Gaborone	Botswana	Sir Seretse Khama Intl
FKKD	DLA	Douala	Cameroon	Douala
FLLS	LUN	Lusaka	Zambia	Lusaka Intl
FVHA	HRE	Harare	Zimbabwe	Harare Intl
FWLI	LLW	Lilongwe	Malawi	Lilongwe Intl
GBYD	BJL	Banjul	Gambia	Banjul Intl
GCLP	LPA	Gran Canaria	Canary Island	Gran Canaria
GCTS	TFS	Tenerife South	Canary Island	Reina Sofia
GCXO	TFN	Tenerife North	Canary Island	Los Rodeos
GOOY	DKR	Dakar	Senegal	Leopold Sedar Senghor
GQNN	NKC	Nouakchott	Mauritania	Nouakchott
GVAC	SID	Sal	Cape Verdi	Amilcar Cabral
HECA	CAI	Cairo	Egypt	Cairo Intl
HELX	LXR	Luxor	Egypt	Luxor
HESN	ASW	Aswan	Egypt	Aswan
HKJK	NBO	Nairobi	Kenya	Jomo Kenyatta
HKMO	MBA	Mombasa	Kenya	Moi
HTDA	DAR	Dar-Es-Salaam	Tanzania	Dar-Es-Salaam Intl
HTKJ	JRO	Kilimanjaro	Tanzania	Kilimanjaro Intl
KABQ	ABQ	Albuquerque	USA New Mexico	Albuquerque Intl Sunport
KAMA	AMA	Amarillo	USA Texas	Amarillo Intl
KATL	ATL	Atlanta	USA Georgia	The Hartsfield Atlanta Intl
KBDL	BDL	Windsor Locks	USA Connecticut	Bradley Intl
KBFI	BFI	Seattle	USA Washington	Boeing Field / King Co. Intl
KBFM	BFM	Mobile	USA Alabama	Mobile Downtown
KBGR	BGR	Bangor	USA Maine	Bangor Intl
KBHM	BHM	Birmingham	USA Alabama	Birmingham Intl
KBOS	BOS	Boston	USA Massachusetts	Logan Intl
KBUF	BUF	Buffalo	USA New York	Buffalo-Niagara Intl
KBWI	BWI	Baltimore	USA Maryland	Baltimor Washington Intl
KCHS	CHS	Charleston	USA South Carolina	Charleston AFB - Intl
KCLE	CLE	Cleveland	USA Ohio	Hopkins Intl
KCVG	CVG	Cincinnati	USA Ohio	Cincinnati / Northern Kentucky Intl
KDAL	DAL	Dallas	USA Texas	Dallas Love
KDEN	DEN	Denver	USA Colorado	Denver Intl
KDFW	DFW	Dallas Fort Worth	USA Texas	Dallas Fort Worth Intl
KDLH	DLH	Duluth	USA Minnesota	Duluth Intl
KDOV	DOV	Dover	USA Delaware	Dover AFB
KDTW	DTW	Detroit	USA Michigan	Detroit Metro Wayne County
KELP	ELP	El Paso	USA Texas	El Paso Intl
KEWR	EWR	Newark	USA New Jersey	Newark Intl
KFAT	FAT	Fresno	USA California	Fresno Yosemite Intl
KFLL	FLL	Fort Lauderdale	USA Florida	Hollywood Intl
KHSV	HSV	Huntsville	USA Alabama	Huntsville Intl. - Jones
KIAB	IAB	Wichita	USA Kansas	McConnell AFB
KIAD	IAD	Washington D.C.	USA D. C.	Washington Dulles Intl
KIAG	IAG	Niagara Falls	USA New York	Niagara Falls Intl
KIAH	IAH	Houston	USA Texas	George Bush Intercontinental / Houston
KICT	ICT	Wichita	USA Kansas	Wichita Mid - Continent
KIND	IND	Indianapolis	USA Indiana	Indianapolis Intl
KJAX	JAX	Jacksonville	USA Florida	Jacksonville Intl
KJFK	JFK	New York	USA New York	Kennedy Intl
KLAS	LAS	Las Vegas	USA Nevada	McCarran Intl
KLAX	LAX	Los Angeles	USA California	Los Angeles Intl
KLCK	LCK	Columbus	USA Ohio	Rickenbacker Intl
KMAF	MAF	Midland	USA Texas	Midland Intl
KMCI	MCI	Kansas City	USA Missouri	Kansas City Intl
KMCO	MCO	Orlando	USA Florida	Orlando Intl

SORTED BY ICAO CODE				
ICAO	IATA	City	Country	Airport
KMEM	MEM	Memphis	USA Tennessee	Memphis Intl
KMIA	MIA	Miami	USA Florida	Miami Intl
KMKE	MKE	Milwaukee	USA Wisconsin	Gen. Mitchell Intl
KMSP	MSP	Minneapolis	USA Minnesota	Minneapolis-St Paul Intl
KMSY	MSY	New Orleans	USA Louisiana	New Orleans Intl
KMZJ	MZJ	Marana	USA Arizona	Pinal Air Park
KNGU	NGU	Norfolk	USA Virginia	Norfolk NAS
KOAK	OAK	Oakland	USA California	Metro Oakland Intl
KOKC	OKC	Oklahoma City	USA Oklahoma	Will Rogers World
KOMA	OMA	Omaha	USA Nebraska	Eppley
KONT	ONT	Ontario	USA California	Ontario Intl
KORD	ORD	Chicago	USA Illinois	O'Hare Intl
KORF	ORF	Norfolk	USA Virginia	Norfolk Intl
KPAE	PAE	Everett	USA Washington	Snohomish Co.
KPDX	PDX	Portland	USA Oregon	Portland Intl
KPHL	PHL	Philadelphia	USA Pennsylvania	Philadelphia Intl
KPHX	PHX	Phoenix	USA Arizona	Phoenix Sky Harbor Intl
KPIT	PIT	Pittsburgh	USA Pennsylvania	Pittsburgh Intl
KPMD	PMD	Palmdale	USA California	Palmdale AF Plant 42
KPSM	PSM	Portsmouth	USA, New Hampshire	Pease Intl Tradeport
KSAN	SAN	San Diego	USA California	San Diego Intl - Lindbergh
KSAT	SAT	San Antonio	USA Texas	San Antonio Intl
KSAV	SAV	Savannah	USA Georgia	Savannah Intl
KSDF	SDF	Louisville	USA Kentucky	Louisville Intl - Standiford
KSEA	SEA	Seattle	USA Washington	Seattle - Tacoma Intl
KSFO	SFO	San Francisco	USA California	San Francisco Intl
KSTL	STL	Saint Louis	USA Missouri	Lambert - Saint Louis Intl
KSWF	SWF	Newburgh	USA New York	Stewart Intl
KTOL	TOL	Toledo	USA Ohio	Toledo Express
KTPA	TPA	Tampa	USA Florida	Tampa Intl
KTUS	TUS	Tucson	USA Arizona	Tucson Intl
KVCV	VCV	Victorville	USA California	Southern California Intl
KWRI	WRI	Wrightstown	USA New Jersey	McGuire AFB
KYIP	YIP	Detroit	USA Michigan	Willow Run
LCLK	LCA	Larnaca	Cyprus	Larnaca Intl
LEBL	BCN	Barcelona	Spain	El Prat
LEMD	MAD	Madrid	Spain	Barajas
LERT	RTA	Rota	Spain	Rota Navy
LETO	TOJ	Madrid	Spain	Torrejon
LEVT	VIT	Vitoria	Spain	Foronda
LEZL	SVQ	Seville	Spain	San Pablo
LFBO	TLS	Toulouse	France	Blagnac
LFLX	CHR	Chateauroux	France	Deols
LFML	MRS	Marseille / Provence	France	Marseille / Provence
LFMN	NCE	Nice / Cote D'Azur	France	Nice / Cote D'Azur
LFPG	CDG	Paris	France	Charles de Gaulle
LFPO	ORY	Paris	France	Orly
LFSB	BSL	Basle-Mulhouse	France	Basle-Mulhouse
LGAT	ATH	Athens	Greece	Athens
LGRP	RHO	Rhodos	Greece	Diagoras
LGTS	SKG	Thessaloniki	Greece	Makedonia
LICZ	NSY	Catania	Italy	Signonella AB
LIMC	MLP	Milan	Italy	Malpensa
LIMF	TRN	Torino	Italy	Caselle
LIMJ	GOA	Genoa	Italy	Sestri
LIPE	BLQ	Bologna	Italy	Borgo Panigale
LIRA	CIA	Rome	Italy	Ciampino
LIRF	FCO	Rome	Italy	Fiumicino
LIRP	PSA	Pisa	Italy	San Giusto
LLBG	TLV	Tel Aviv	Israel	Ben Gurion
LOWL	LNZ	Linz	Austria	Linz

SORTED BY ICAO CODE

ICAO	IATA	City	Country	Airport
LOWW	VIE	Vienna	Austria	Schwechat
LPPR	OPO	Porto	Portugal	Francisco' Sa Carneiro
LPPT	LIS	Lisbon	Portugal	Lisbon
LSGG	GVA	Geneva	Switzerland	Cointrin
LSZH	ZRH	Zurich	Switzerland	Zurich
LTAC	ESB	Ankara	Turkey	Esenboga
LTBA	IST	Istanbul	Turkey	Ataturk
LWSK	SKP	Skopje	Macedonia	Skopje
MDSO	SDQ	Santo Domingo	Dominican Republic	Las Americas Intl
MGGT	GUA	Guatemala City	Guatemala	La Aurora Intl
MMAA	ACA	Acapulco	Mexico	Gen Juan N. Alvarez Intl
MMGL	GDL	Guadalajara	Mexico	Don Miguel Hidalgo Intl
MMMX	MEX	Mexico City	Mexico	Lic Benito Juarez Intl
MPHO	HOW	Balboa	Panama	Howard AFB
MPTO	PTY	Panama City	Panama	Tocumen Intl
MROC	SJO	San Jose	Costa Rica	Alajuela (Juan Santamaria Intl)
MSLP	SAL	San Salvador	El Salvador	El Salvador Intl
MUGM	NBW	Guantanamo Bay	Cuba	Guantanamo Bay NAS
MYGF	FPO	Freeport	Bahamas	Freeport Intl
MYNN	NAS	Nassau	Bahamas	Nassau Intl
NFFN	NAN	Nadi	Fiji Islands	Nadi Intl
NFTF	TBU	Nuku'alofa	Tonga	Fua'amotu Intl
NSFA	APW	Apia	Western Samoa	Faleolo Intl
NSTU	PPG	Pago Pago	American Samoa	Pago Pago Intl
NVVV	VLI	Port Vila	Vanuatu	Bauerfield
NWWW	NOU	Noumea	New Caledonia	Tontouta
NZAA	AKL	Auckland	New Zealand	Auckland Intl
NZCH	CHC	Christchurch	New Zealand	Christchurch Intl
OBBI	BAH	Bahrain	Bahrain	Bahrain Intl
OEDF	DMM	Dammam	Saudi Arabia	King Fahd Intl
OEDR	DHA	Dhahran	Saudi Arabia	King Abdulaziz AB
OEJN	JED	Jeddah	Saudi Arabia	King Abdulaziz Intl
OEMA	MED	Madinah	Saudi Arabia	Prince Mohammad Bin Abdulaziz Intl
OERK	RUH	Riyadh	Saudi Arabia	King Khalid Intl
OERY		Riyadh	Saudi Arabia	Riyadh AB
OJAI	AMM	Amman	Jordan	Queen Alia Intl
OKBK	KWI	Kuwait	Kuwait	Kuwait Intl
OMAA	AUH	Abu Dhabi	U.A.E.	Abu Dhabi Intl
OMAL	AAN	Al Ain	U.A.E.	Al Ain Intl
OMDB	DXB	Dubai	U.A.E.	Dubai Intl
OMFJ	FJR	Fujairah	UAE	Fujairah Intl
OMRK	RKT	Ras Al Khaimah	U.A.E.	Ras Al Khaimah Intl
OMSJ	SHJ	Sharjah	U.A.E.	Sharjah Intl
OOMS	MCT	Muscat	Oman	Seeb Intl
OPKC	KHI	Karachi	Pakistan	Quaid-E-Azam Intl
OPLA	LHE	Lahore	Pakistan	Lahore Intl
OPNH	WNS	Nawabshah	Pakistan	Nawabshah
OSDI	DAM	Damascus	Syria	Damascus Intl
OTBD	DOH	Doha	Qatar	Doha Intl
PACD	CDB	Cold Bay	USA Alaska	Cold Bay
PAED	EDF	Anchorage	USA Alaska	Elmendorf AFB
PAEI	EIL	Fairbanks	USA Alaska	Eielson AFB
PAFA	FAI	Fairbanks	USA Alaska	Fairbanks Intl
PANC	ANC	Anchorage	USA Alaska	Anchorage Intl
PASY	SYA	Shemya	USA Alaska	Eareckson AS
PHJR		Kapolei	USA Hawaii	Kalaeloa
PHNL	HNL	Honolulu	USA Hawaii	Honolulu Intl
PHTO	ITO	Hilo	USA Hawaii	Hilo Intl
RCKH	KHH	Kaohsiung	Taiwan	Kaohsiung Intl
RCSS	TSA	Taipei	Taiwan	Sungshan
RCTP	TPE	Taipei	Taiwan	Chiang Kai Shek Intl

SORTED BY ICAO CODE

ICAO	IATA	City	Country	Airport
RJAA	NRT	Tokyo Narita	Japan	Narita (New Tokyo Intl)
RJBB	KIX	Osaka	Japan	Kansai Intl
RJCC	CTS	Sapporo	Japan	New Chitose
RJCH	HKD	Hakodate	Japan	Hakodate
RJCJ	OKD	Sapporo	Japan	Chitose
RJFF	FUK	Fukuoka	Japan	Fukuoka
RJFK	KOJ	Kagoshima	Japan	Kagoshima
RJFU	NGS	Nagasaki	Japan	Nagasaki
RJNN	NGO	Nagoya	Japan	Nagoya
RJOI	IWA	Iwakuni	Japan	Iwakuni MCAS
RJOO	ITM	Osaka	Japan	Osaka Intl
RJSM	MSJ	Misawa	Japan	Misawa AB
RJSS	SDJ	Sendai	Japan	Sendai
RJTT	HND	Tokyo Haneda	Japan	Tokyo Intl
RJTY	OKO	Tokyo Yokota	Japan	Yokota AB
RKJK	KUV	Kunsan	Korea	Kunsan AB
RKPC	CJU	Cheju	Korea	Cheju Intl
RKSO	OSN	Osan	Korea	Osan AB
RKSS	SEL	Seoul	Korea	Kimpo Intl
ROAH	OKA	Naha, Okinawa	Japan	Naha
RODN	DNA	Okinawa Island	Japan	Kadena AB
RPLB	SFS	Subic Bay	Philippines	Subic Bay Intl
RPLC	CRK	Angeles - Clark	Philippines	Clark Intl.
RPLL	MNL	Manila	Philippines	Ninoy Aquino Intl
SAAR	ROS	Rosario	Argentina	Rosario
SACO	COR	Cordoba	Argentina	Ing. A. L. V. Taravella Intl
SAEZ	EZE	Buenos Aires	Argentina	Ezeiza Intl. - Ministro Pistarini
SAME	MDZ	Mendoza	Argentina	El Plumerillo
SASJ	JUJ	Jujuy	Argentina	Gobernador Horacio Guzman
SBBE	BEL	Belem	Brazil	Val De Caes
SBBR	BSB	Brasilia	Brazil	Pres Juscelino Kubitschek Intl
SBCF	CNF	Belo Horizonte	Brazil	Tancredo Neves Intl
SBCT	CWB	Curitiba	Brazil	Afonso Pena Intl
SBEG	MAO	Manaus	Brazil	Eduardo Gomes Intl
SBGL	GIG	Rio De Janeiro	Brazil	Galeao Antonio Carlos Jobin Intl
SBGR	GRU	Sao Paulo	Brazil	Sao Paulo / Intl - Guarulhos
SBKP	VCP	Campinas	Brazil	Viracopos Intl
SBPA	POA	Porto Alegre	Brazil	Salgado Filho Intl
SBRF	REC	Recife	Brazil	Guararapes Intl
SBSN	STM	Santarem	Brazil	Santarem Intl
SBSV	SSA	Salvador	Brazil	Dep. L.E. Magal'haes Intl
SCEL	SCL	Santiago	Chile	Arturo Merino Benitez Intl
SCFA	ANF	Antofagasta	Chile	Cerro Moreno Intl
SEGU	GYE	Guayaquil	Ecuador	Simon Bolivar Intl
SEMT	MEC	Manta	Ecuador	Eloy Alfaro Intl
SEQU	UIO	Quito	Ecuador	Mariscal Sucre Intl
SGAS	ASU	Asuncion	Paraguay	Asuncion / Silvio Pettrossi Intl
SGCO		Concepcion	Paraguay	Ter. Crl. Carmelo Peralta
SGES	AGT	Ciudad del Este	Paraguay	Guarani Intl
SKBO	BOG	Santafe De Bogota	Columbia	Eldorado Intl
SKBQ	BAQ	Barranquilla	Columbia	Ernesto Cortissoz
SKCL	CLO	Cali	Columbia	Alfonso Bonilla Aragon Intl
SKRG	MDE	Rionegro	Columbia	Jose Maria Cordova
SLVR	VVI	Santa Cruz	Bolivia	Viru Viru Intl
SMJP	PBM	Zandery	Suriname	J. A. Pengel Intl
SPIM	LIM	Lima-Callao	Peru	Jorge Chavez Intl
SPQU	AQP	Arequipa	Peru	Rodriguez Ballon
SPSO	PIO	Pisco	Peru	Pisco
SUMU	MVD	Montevideo	Uruguay	Carrasco Intl. / Gen Cesareo L. Berisso
SVMC	MAR	Maracaibo	Venezuela	La Chinita Intl
SVMI	CCS	Maiquetia - Caracas	Venezuela	Simon Bolivar Intl

SORTED BY ICAO CODE

ICAO	IATA	City	Country	Airport
TBPB	BGI	Barbados, Bridgetown	British West Indies	Grantley Adams Intl
TJSJ	SJU	San Juan	Puerto Rico	Luis Munoz Marin Intl
TNCC	CUR	Curacao Island	Netherland Antilles	Hato Intl
TTPP	POS	Port of Spain	Trinidad	Piarco Intl
TXKF	BDA	Bermuda	Bermuda Islands	Bermuda Intl
UAAA	ALA	Almaty	Kazakhstan	Almaty
UGGG	TBS	Tbilisi	Georgia	Lochini
UHHH	KHV	Khabarovsk	Russia	Khabarovsk Novy
UHMM	GDX	Magadan	Russia	Sokol
UHPP	PCK	Petropavlovsk Kamchatsky	Russia	Yelizovo
UHWV	VVO	Vladivostok	Russia	Knevichi
UKBB	KBP	Kyiv	Ukraine	Boryspil
ULLI	LED	Saint Petersburg	Russia	Pulkovo
UMMS	MSQ	Minsk	Belarus	Minsk-2
UTTT	TAS	Tashkent	Uzbekistan	Yuzhny
UUEE	SVO	Moscow	Russia	Sheremetyevo
VAAH	AMD	Ahmedabad	India	Ahmedabad
VABB	BOM	Mumbai	India	Chhatrapati Shivaji Intl
VCBI	CMB	Colombo	Sri Lanka	Bandaranaike Intl
VECC	CCU	Calcutta	India	Netaji Subhas Chandra Bose Intl
VGZR	DAC	Dhaka	Bangladesh	Zia Intl
VHHH	HKG	Hong Kong	Peoples Republic of China	Hong Kong Intl
VIDP	DEL	Delhi	India	Indira Gandhi Intl
VMMC	MFM	Macau	Macau	Macau Intl
VOBG	BLR	Bangalore	India	Bangalore
VOMM	MAA	Chennai	India	Chennai Intl
VTBD	BKK	Bangkok	Thailand	Bangkok Intl
VTBU	UTP	Rayong	Thailand	U-Taphao Intl
VTCC	CNX	Chiang Mai	Thailand	Chiang Mai Intl
VTSP	HKT	Phuket	Thailand	Phuket Intl
WBGG	KCH	Kuching	Malaysia	Kuching Intl
WBKK	BKI	Kota Kinabalu	Malaysia	Kota Kinabalu
WIIH	HLP	Jakarta-Halim	Indonesia	Halim Intl
WIII	CGK	Jakarta	Indonesia	Soekarno-Hatta Intl
WIMM	MES	Medan	Indonesia	Polonia
WMKJ	JHB	Johar Bahru	Malaysia	Sultan Ismail
WMKK	KUL	Kuala Lumpur	Malaysia	Kuala Lumpur Intl - Sepang
WMKP	PEN	Penang Island	Malaysia	Penang Intl
WMSA	SZB	Kuala Lumpur (old airport)	Malaysia	Sultan Abdul Aziz Shah-Subang Intl
WRSJ	SUB	Surabaya	Indonesia	Juanda
WSAP	QPG	Singapore	Singapore	Paya Lebar Aero
WSSS	SIN	Singapore	Singapore	Changi
YBAL	ASP	Alice Springs	Australia Northern Territory	Alice Springs
YBBN	BNE	Brisbane	Australia Queensland	Brisbane Intl
YBCS	CNS	Cairns	Australia Queensland	Cairns Intl
YMAV	AVV	Avalon	Australia Victoria	Avalon
YMML	MEL	Melbourne	Australia Victoria	Melbourne Intl
YPAD	ADL	Adelaide	Australia South Australia	Adelaide Intl
YPDN	DRW	Darwin	Australia Northern Territory	Darwin Intl
YPPH	PER	Perth	Australia Western Aust.	Perth Intl
YSSY	SYD	Sydney	Australia NewSouthWales	Kingford Smith Intl
ZBAA	PEK	Beijing	Peoples Republic of China	Capital
ZBTJ	TSN	Tianjin	Peoples Republic of China	Binhai
ZGGG	CAN	Guangzhou	Peoples Republic of China	Baiyun
ZGSZ	SZX	Shenzhen	Peoples Republic of China	Huangtian
ZSHC	HGH	Hangzhou	Peoples Republic of China	Jiangqiao
ZSPD	PVG	Shanghai	Peoples Republic of China	Pudong
ZSSS	SHA	Shanghai	Peoples Republic of China	Hongqiao
ZYTL	DLC	Dalian	Peoples Republic of China	Zhoushuizi

SORTED BY IATA CODE				
ICAO	IATA	City	Country	Airport
OMAL	AAN	Al Ain	U.A.E.	Al Ain Intl
DIAP	ABJ	Abidjan	Ivory Coast	Felix Ho'uphouet-Boigny
KABQ	ABQ	Albuquerque	USA New Mexico	Albuquerque Intl Sunport
MMAA	ACA	Acapulco	Mexico	Gen Juan N. Alvarez Intl
DGAA	ACC	Accra	Ghana	Kotoka Intl
YPAD	ADL	Adelaide	Australia South Australia	Adelaide Intl
SGES	AGT	Ciudad del Este	Paraguay	Guarani Intl
NZAA	AKL	Auckland	New Zealand	Auckland Intl
UAAA	ALA	Almaty	Kazakhstan	Almaty
KAMA	AMA	Amarillo	USA Texas	Amarillo Intl
VAAH	AMD	Ahmedabad	India	Ahmedabad
OJAI	AMM	Amman	Jordan	Queen Alia Intl
EHAM	AMS	Amsterdam	Netherlands	Schiphol
PANC	ANC	Anchorage	USA Alaska	Anchorage Intl
SCFA	ANF	Antofagasta	Chile	Cerro Moreno Intl
NSFA	APW	Apia	Western Samoa	Faleolo Intl
SPQU	AQP	Arequipa	Peru	Rodriguez Ballon
ESSA	ARN	Stockholm	Sweden	Arlanda
YBAL	ASP	Alice Springs	Australia Northern Territory	Alice Springs
SGAS	ASU	Asuncion	Paraguay	Asuncion / Silvio Pettirossi Intl
HESN	ASW	Aswan	Egypt	Aswan
LGAT	ATH	Athens	Greece	Athens
KATL	ATL	Atlanta	USA Georgia	The Hartsfield Atlanta Intl
OMAA	AUH	Abu Dhabi	U.A.E.	Abu Dhabi Intl
YMAV	AVV	Avalon	Australia Victoria	Avalon
OBBI	BAH	Bahrain	Bahrain	Bahrain Intl
SKBQ	BAQ	Barranquilla	Columbia	Ernesto Cortissoz
LEBL	BCN	Barcelona	Spain	El Prat
TXKF	BDA	Bermuda	Bermuda Islands	Bermuda Intl
KBDL	BDL	Windsor Locks	USA Connecticut	Bradley Intl
SBBE	BEL	Belem	Brazil	Val De Caes
KBFI	BFI	Seattle	USA Washington	Boeing Field / King Co. Intl
KBFM	BFM	Mobile	USA Alabama	Mobile Downtown
FABL	BFN	Bloemfontein	South African Rep	Bloemfontein
EGAA	BFS	Belfast	United Kingdom	Aldergrove
TBPB	BGI	Barbados, Bridgetown	British West Indies	Grantley Adams Intl
ENBR	BGO	Bergen	Norway	Flesland
KBGR	BGR	Bangor	USA Maine	Bangor Intl
KBHM	BHM	Birmingham	USA Alabama	Birmingham Intl
EGBB	BHX	Birmingham	United Kingdom	Birmingham
GBYD	BJL	Banjul	Gambia	Banjul Intl
WBKK	BKI	Kota Kinabalu	Malaysia	Kota Kinabalu
VTBD	BKK	Bangkok	Thailand	Bangkok Intl
EKBI	BLL	Billund	Denmark	Billund
LIPE	BLQ	Bologna	Italy	Borgo Panigale
VOBG	BLR	Bangalore	India	Bangalore
YBBN	BNE	Brisbane	Australia Queensland	Brisbane Intl
SKBO	BOG	Santafe De Bogota	Columbia	Eldorado Intl
VABB	BOM	Mumbai	India	Chhatrapati Shivaji Intl
KBOS	BOS	Boston	USA Massachusetts	Logan Intl
EBBR	BRU	Brussels	Belgium	Brussels Natl
SBBR	BSB	Brasilia	Brazil	Pres Juscelino Kubitschek Intl
LFSB	BSL	Basle-Mulhouse	France	Basle-Mulhouse
KBUF	BUF	Buffalo	USA New York	Buffalo-Niagara Intl
KBWI	BWI	Baltimore	USA Maryland	Baltimor Washington Intl
HECA	CAI	Cairo	Egypt	Cairo Intl
ZGGG	CAN	Guangzhou	Peoples Republic of China	Baiyun
SVMI	CCS	Maiquetia - Caracas	Venezuela	Simon Bolivar Intl
VECC	CCU	Calcutta	India	Netaji Subhas Chandra Bose Intl
PACD	CDB	Cold Bay	USA Alaska	Cold Bay
LFPG	CDG	Paris	France	Charles de Gaulle

SORTED BY IATA CODE

ICAO	IATA	City	Country	Airport
WIII	CGK	Jakarta	Indonesia	Soekarno-Hatta Intl
EDDK	CGN	Cologne-Bonn	Germany	Cologne-Bonn
NZCH	CHC	Christchurch	New Zealand	Christchurch Intl
LFLX	CHR	Chateauroux	France	Deols
KCHS	CHS	Charleston	USA South Carolina	Charleston AFB - Intl
LIRA	CIA	Rome	Italy	Ciampino
RKPC	CJU	Cheju	Korea	Cheju Intl
KCLE	CLE	Cleveland	USA Ohio	Hopkins Intl
SKCL	CLO	Cali	Columbia	Alfonso Bonilla Aragon Intl
VCBI	CMB	Colombo	Sri Lanka	Bandaranaike Intl
SBCF	CNF	Belo Horizonte	Brazil	Tancredo Neves Intl
YBCS	CNS	Cairns	Australia Queensland	Cairns Intl
VTCC	CNX	Chiang Mai	Thailand	Chiang Mai Intl
SACO	COR	Cordoba	Argentina	Ing. A. L. V. Taravella Intl
EKCH	CPH	Copenhagen,	Denmark	Kastrup
FACT	CPT	Cape Town	South African Rep	Cape Town Intl
RPLC	CRK	Angeles - Clark	Philippines	Clark Intl.
RJCC	CTS	Sapporo	Japan	New Chitose
TNCC	CUR	Curacao Island	Netherland Antilles	Hato Intl
KCVG	CVG	Cincinnati	USA Ohio	Cincinnati / Northern Kentucky Intl
SBCT	CWB	Curitiba	Brazil	Afonso Pena Intl
VGZR	DAC	Dhaka	Bangladesh	Zia Intl
KDAL	DAL	Dallas	USA Texas	Dallas Love
OSDI	DAM	Damascus	Syria	Damascus Intl
HTDA	DAR	Dar-Es-Salaam	Tanzania	Dar-Es-Salaam Intl
VIDP	DEL	Delhi	India	Indira Gandhi Intl
KDEN	DEN	Denver	USA Colorado	Denver Intl
KDFW	DFW	Dallas Fort Worth	USA Texas	Dallas Fort Worth Intl
OEDR	DHA	Dhahran	Saudi Arabia	King Abdulaziz AB
GOOY	DKR	Dakar	Senegal	Leopold Sedar Senghor
FKKD	DLA	Douala	Cameroon	Douala
ZYTL	DLC	Dalian	Peoples Republic of China	Zhoushuizi
KDLH	DLH	Duluth	USA Minnesota	Duluth Intl
OEDF	DMM	Dammam	Saudi Arabia	King Fahd Intl
RODN	DNA	Okinawa Island	Japan	Kadena AB
OTBD	DOH	Doha	Qatar	Doha Intl
KDOV	DOV	Dover	USA Delaware	Dover AFB
YPDN	DRW	Darwin	Australia Northern Territory	Darwin Intl
KDTW	DTW	Detroit	USA Michigan	Detroit Metro Wayne County
EIDW	DUB	Dublin	Ireland	Dublin Intl
FADN	DUR	Durban	South African Rep	Durban Intl
EDDL	DUS	Dusseldorf	Germany	Dusseldorf
OMDB	DXB	Dubai	U.A.E.	Dubai Intl
PAED	EDF	Anchorage	USA Alaska	Elmendorf AFB
PAEI	EIL	Fairbanks	USA Alaska	Eielson AFB
KELP	ELP	El Paso	USA Texas	El Paso Intl
LTAC	ESB	Ankara	Turkey	Esenboga
KEWR	EWR	Newark	USA New Jersey	Newark Intl
SAEZ	EZE	Buenos Aires	Argentina	Ezeiza Intl. - Ministro Pistarini
PAFA	FAI	Fairbanks	USA Alaska	Fairbanks Intl
KFAT	FAT	Fresno	USA California	Fresno Yosemite Intl
LIRF	FCO	Rome	Italy	Fiumicino
OMFJ	FJR	Fujairah	UAE	Fujairah Intl
KFLL	FLL	Fort Lauderdale	USA Florida	Hollywood Intl
MYGF	FPO	Freeport	Bahamas	Freeport Intl
EDDF	FRA	Frankfurt / Main	Germany	Frankfurt / Main
RJFF	FUK	Fukuoka	Japan	Fukuoka
FBSK	GBE	Gaborone	Botswana	Sir Seretse Khama Intl
MMGL	GDL	Guadalajara	Mexico	Don Miguel Hidalgo Intl
UHMM	GDX	Magadan	Russia	Sokol
ENGM	GEN	Oslo	Norway	Gardermoen

SORTED BY IATA CODE

ICAO	IATA	City	Country	Airport
SBGL	GIG	Rio De Janeiro	Brazil	Galeao Antonio Carlos Jobin Intl
EGPF	GLA	Glasgow	United Kingdom	Glasgow
LIMJ	GOA	Genoa	Italy	Sestri
ESGG	GOT	Goteborg	Sweden	Landvetter
SBGR	GRU	Sao Paulo	Brazil	Sao Paulo / Intl - Guarulhos
MGGT	GUA	Guatemala City	Guatemala	La Aurora Intl
LSGG	GVA	Geneva	Switzerland	Cointrin
SEGU	GYE	Guayaquil	Equador	Simon Bolivar Intl
EDDV	HAN	Hannover	Germany	Hannover
EDDH	HAM	Hamburg	Germany	Hamburg
EFHK	HEL	Helsinki	Finland	Vantaa
ZSHC	HGH	Hangzhou	Peoples Republic of China	Jiangqiao
EDFH	HHN	Hahn	Germany	Hahn
RJCH	HKD	Hakodate	Japan	Hakodate
VHHH	HKG	Hong Kong	Peoples Republic of China	Hong Kong Intl
VTSP	HKT	Phuket	Thailand	Phuket Intl
WIIIH	HLP	Jakarta-Halim	Indonesia	Halim Intl
RJTT	HND	Tokyo Haneda	Japan	Tokyo Intl
PHNL	HNL	Honolulu	USA Hawaii	Honolulu Intl
MPHO	HOW	Balboa	Panama	Howard AFB
FVHA	HRE	Harare	Zimbabwe	Harare Intl
KHSV	HSV	Huntsville	USA Alabama	Huntsville Intl. - Jones
KIAB	IAB	Wichita	USA Kansas	McConnell AFB
KIAD	IAD	Washington D.C.	USA D. C.	Washington Dulles Intl
KIAG	IAG	Niagara Falls	USA New York	Niagara Falls Intl
KIAH	IAH	Houston	USA Texas	George Bush Intercontinental / Houston
KICT	ICT	Wichita	USA Kansas	Wichita Mid - Continent
KIND	IND	Indianapolis	USA Indiana	Indianapolis Intl
LTBA	IST	Istanbul	Turkey	Ataturk
RJOO	ITM	Osaka	Japan	Osaka Intl
PHTO	ITO	Hilo	USA Hawaii	Hilo Intl
RJOI	IWA	Iwakuni	Japan	Iwakuni MCAS
KJAX	JAX	Jacksonville	USA Florida	Jacksonville Intl
OEJN	JED	Jeddah	Saudi Arabia	King Abdulaziz Intl
KJFK	JFK	New York	USA New York	Kennedy Intl
WMKJ	JHB	Johar Bahru	Malaysia	Sultan Ismail
FAJS	JNB	Johannesburg	South African Rep	Johannesburg Intl
HTKJ	JRO	Kilimanjaro	Tanzania	Kilimanjaro Intl
SASJ	JUJ	Jujuy	Argentina	Gobernador Horacio Guzman
DNKN	KAN	Kano	Nigeria	Mallam Aminu Kano
UKBB	KBP	Kyiv	Ukraine	Boryspil
WBGG	KCH	Kuching	Malaysia	Kuching Intl
BIKF	KEF	Keflavik	Iceland	Keflavik
RCKH	KHH	Kaohsiung	Taiwan	Kaohsiung Intl
OPKC	KHI	Karachi	Pakistan	Quaid-E-Azam Intl
UHHH	KHV	Khabarovsk	Russia	Khabarovsk Novy
RJBB	KIX	Osaka	Japan	Kansai Intl
RJFK	KOJ	Kagoshima	Japan	Kagoshima
WMKK	KUL	Kuala Lumpur	Malaysia	Kuala Lumpur Intl - Sepang
RKJK	KUV	Kunsan	Korea	Kunsan AB
OKBK	KWI	Kuwait	Kuwait	Kuwait Intl
KLAS	LAS	Las Vegas	USA Nevada	McCarran Intl
KLAX	LAX	Los Angeles	USA California	Los Angeles Intl
LCLK	LCA	Larnaca	Cyprus	Larnaca Intl
KLCK	LCK	Columbus	USA Ohio	Rickenbacker Intl
ULLI	LED	Saint Petersburg	Russia	Pulkovo
DXXX	LFW	Lome	Togo	Tokoin
EBLG	LGG	Liege	Belgium	Liege
EGKK	LGW	London-Gatwick	United Kingdom	Gatwick
OPLA	LHE	Lahore	Pakistan	Lahore Intl
EGLL	LHR	London-Heathrow	United Kingdom	Heathrow

SORTED BY IATA CODE				
ICAO	IATA	City	Country	Airport
SPIM	LIM	Lima-Callao	Peru	Jorge Chavez Intl
LPPT	LIS	Lisbon	Portugal	Lisbon
FWLI	LLW	Lilongwe	Malawi	Lilongwe Intl
LOWL	LNZ	Linz	Austria	Linz
DNMM	LOS	Lagos	Nigeria	Murtala Muhammed
GCLP	LPA	Gran Canaria	Canary Island	Gran Canaria
FLLS	LUN	Lusaka	Zambia	Lusaka Intl
ELLX	LUX	Luxembourg	Luxembourg	Luxembourg
HELX	LXR	Luxor	Egypt	Luxor
VOMM	MAA	Chennai	India	Chennai Intl
LEMD	MAD	Madrid	Spain	Barajas
KMAF	MAF	Midland	USA Texas	Midland Intl
EGCC	MAN	Manchester	United Kingdom	Manchester
SBEG	MAO	Manaus	Brazil	Eduardo Gomes Intl
SVMC	MAR	Maracaibo	Venezuela	La Chinita Intl
HKMO	MBA	Mombasa	Kenya	Moi
FAMM	MBD	Mafikeng	South African Rep	Mafikeng Intl
KMCI	MCI	Kansas City	USA Missouri	Kansas City Intl
KMCO	MCO	Orlando	USA Florida	Orlando Intl
OOMS	MCT	Muscat	Oman	Seeb Intl
SKRG	MDE	Rionegro	Columbia	Jose Maria Cordova
SAME	MDZ	Mendoza	Argentina	El Plumerillo
SEMT	MEC	Manta	Equador	Eloy Alfaro Intl
OEMA	MED	Madinah	Saudi Arabia	Prince Mohammad Bin Abdulaziz Intl
YMML	MEL	Melbourne	Australia Victoria	Melbourne Intl
KMEM	MEM	Memphis	USA Tennessee	Memphis Intl
WIMM	MES	Medan	Indonesia	Polonia
MMMXX	MEX	Mexico City	Mexico	Lic Benito Juarez Intl
VMMC	MFM	Macau	Macau	Macau Intl
KMIA	MIA	Miami	USA Florida	Miami Intl
KMKE	MKE	Milwaukee	USA Wisconsin	Gen. Mitchell Intl
ESMS	MMX	Malmo	Sweden	Sturup
RPLL	MNL	Manila	Philippines	Ninoy Aquino Intl
LFML	MRS	Marseille / Provence	France	Marseille / Provence
RJSM	MSJ	Misawa	Japan	Misawa AB
KMSP	MSP	Minneapolis	USA Minnesota	Minneapolis-St Paul Intl
UMMS	MSQ	Minsk	Belarus	Minsk-2
EHBK	MST	Maastricht	Netherlands	Maastricht-Aachen
KMSY	MSY	New Orleans	USA Louisiana	New Orleans Intl
EDDM	MUC	Munich	Germany	Munich
SUMU	MVD	Montevideo	Uruguay	Carrasco Intl. / Gen Cesareo L. Berisso
LIMC	MXP	Milan	Italy	Malpensa
KMZJ	MZJ	Marana	USA Arizona	Pinal Air Park
NFFN	NAN	Nadi	Fiji Islands	Nadi Intl
MYNN	NAS	Nassau	Bahamas	Nassau Intl
HKJK	NBO	Nairobi	Kenya	Jomo Kenyatta
MUGM	NBW	Guantanamo Bay	Cuba	Guantanamo Bay NAS
LFMN	NCE	Nice / Cote D'Azur	France	Nice / Cote D'Azur
RJNN	NGO	Nagoya	Japan	Nagoya
RJFU	NGS	Nagasaki	Japan	Nagasaki
KNGU	NGU	Norfolk	USA Virginia	Norfolk NAS
GQNN	NKC	Nouakchott	Mauritania	Nouakchott
NWWW	NOU	Noumea	New Caledonia	Tontouta
RJAA	NRT	Tokyo Narita	Japan	Narita (New Tokyo Intl)
LICZ	NSY	Catania	Italy	Signonella AB
KOAK	OAK	Oakland	USA California	Metro Oakland Intl
ROAH	OKA	Naha, Okinawa	Japan	Naha
KOKC	OKC	Oklahoma City	USA Oklahoma	Will Rogers World
RJCJ	OKD	Sapporo	Japan	Chitose
RJTY	OKO	Tokyo Yokota	Japan	Yokota AB
KOMA	OMA	Omaha	USA Nebraska	Eppley

SORTED BY IATA CODE

ICAO	IATA	City	Country	Airport
KONT	ONT	Ontario	USA California	Ontario Intl
LPPR	OPO	Porto	Portugal	Francisco' Sa Carneiro
KORD	ORD	Chicago	USA Illinois	O'Hare Intl
KORF	ORF	Norfolk	USA Virginia	Norfolk Intl
LFPO	ORY	Paris	France	Orly
RKSO	OSN	Osan	Korea	Osan AB
EBOS	OST	Ostend	Belgium	Ostend
KPAE	PAE	Everett	USA Washington	Snohomish Co.
SMJP	PBM	Zandery	Suriname	J. A. Pengel Intl
UHPP	PCK	Petropavlovsk Kamchatsky	Russia	Yelizovo
KPDX	PDX	Portland	USA Oregon	Portland Intl
ZBAA	PEK	Beijing	Peoples Republic of China	Capital
WMKP	PEN	Penang Island	Malaysia	Penang Intl
YPPH	PER	Perth	Australia Western Aust.	Perth Intl
DNPO	PHC	Port Harcourt	Nigeria	Port Harcourt
KPHL	PHL	Philadelphia	USA Pennsylvania	Philadelphia Intl
KPHX	PHX	Phoenix	USA Arizona	Phoenix Sky Harbor Intl
EGPK	PIK	Prestwick	United Kingdom	Prestwick
SPSO	PIO	Pisco	Peru	Pisco
KPIT	PIT	Pittsburgh	USA Pennsylvania	Pittsburgh Intl
KPMD	PMD	Palmdale	USA California	Palmdale AF Plant 42
SBPA	POA	Porto Alegre	Brazil	Salgado Filho Intl
TTPP	POS	Port of Spain	Trinidad	Piarco Intl
NSTU	PPG	Pago Pago	American Samoa	Pago Pago Intl
LIRP	PSA	Pisa	Italy	San Giusto
KPSM	PSM	Portsmouth	USA, New Hampshire	Pease Intl Tradeport
MPTO	PTY	Panama City	Panama	Tocumen Intl
ZSPD	PVG	Shanghai	Peoples Republic of China	Pudong
WSAP	QPG	Singapore	Singapore	Paya Lebar Aero
SBRF	REC	Recife	Brazil	Guararapes Intl
LGRP	RHO	Rhodos	Greece	Diagoras
OMRK	RKT	Ras Al Khaimah	U.A.E.	Ras Al Khaimah Intl
ETAR	RMS	Ramstein	Germany	Ramstein AB
SAAR	ROS	Rosario	Argentina	Rosario
LERT	RTA	Rota	Spain	Rota Navy
OERK	RUH	Riyadh	Saudi Arabia	King Khalid Intl
MSLP	SAL	San Salvador	El Salvador	El Salvador Intl
KSAN	SAN	San Diego	USA California	San Diego Intl - Lindbergh
KSAT	SAT	San Antonio	USA Texas	San Antonio Intl
KSAV	SAV	Savannah	USA Georgia	Savannah Intl
SCEL	SCL	Santiago	Chile	Arturo Merino Benitez Intl
KSDF	SDF	Louisville	USA Kentucky	Louisville Intl - Standiford
RJSS	SDJ	Sendai	Japan	Sendai
MDSD	SDQ	Santo Domingo	Dominican Republic	Las Americas Intl
KSEA	SEA	Seattle	USA Washington	Seattle - Tacoma Intl
RKSS	SEL	Seoul	Korea	Kimpo Intl
BGSF	SFJ	Sondre Stromfjord	Greenland	Kangerlussuaq
KSFO	SFO	San Franscisco	USA California	San Franscisco Intl
RPLB	SFS	Subic Bay	Philippines	Subic Bay Intl
ZSSS	SHA	Shanghai	Peoples Republic of China	Hongqiao
OMSJ	SHJ	Sharjah	U.A.E	Sharjah Intl
GVAC	SID	Sal	Cape Verdi	Amilcar Cabral
WSSS	SIN	Singapore	Singapore	Changi
MROC	SJO	San Jose	Costa Rica	Alajuela (Juan Santamaria Intl)
TJSJ	SJU	San Juan	Puerto Rico	Luis Munoz Marin Intl
LGTS	SKG	Thessaloniki	Greece	Makedonia
LWSK	SKP	Skopje	Macedonia	Skopje
EINN	SNN	Shannon	Ireland	Shannon
SBSV	SSA	Salvador	Brazil	Dep. L.E. Magal'haes Intl
KSTL	STL	Saint Louis	USA Missouri	Lambert - Saint Louis Intl
SBSN	STM	Santarem	Brazil	Santarem Intl

SORTED BY IATA CODE

ICAO	IATA	City	Country	Airport
EGSS	STN	London-Stansted	United Kingdom	Stansted
EDDS	STR	Stuttgart	Germany	Stuttgart
WRSJ	SUB	Surabaya	Indonesia	Juanda
ENZV	SVG	Stavanger	Norway	Sola
UUEE	SVO	Moscow	Russia	Sheremetyevo
LEZL	SVQ	Seville	Spain	San Pablo
KSWF	SWF	Newburgh	USA New York	Stewart Intl
PASY	SYA	Shemya	USA Alaska	Eareckson AS
YSSY	SYD	Sydney	Australia NewSouthWales	Kingford Smith Intl
WMSA	SZB	Kuala Lumpur (old airport)	Malaysia	Sultan Abdul Aziz Shah-Subang Intl
ZGSZ	SZX	Shenzhen	Peoples Republic of China	Huangtian
UTTT	TAS	Tashkent	Uzbekistan	Yuzhny
UGGG	TBS	Tbilisi	Georgia	Lochini
NFTF	TBU	Nuku'alofa	Tonga	Fua'amotu Intl
GCXO	TFN	Tenerife North	Canary Island	Los Rodeos
GCTS	TFS	Tenerife South	Canary Island	Reina Sofia
BGTL	THU	Thule	Greenland	Thule AB
EFTU	TKU	Turku	Finland	Turku
LFBO	TLS	Toulouse	France	Blagnac
LLBG	TLV	Tel Aviv	Isreal	Ben Gurion
LETO	TOJ	Madrid	Spain	Torrejon
KTOL	TOL	Toledo	USA Ohio	Toledo Express
KTPA	TPA	Tampa	USA Florida	Tampa Intl
RCTP	TPE	Taipei	Taiwan	Chiang Kai Shek Intl
LIMF	TRN	Torino	Italy	Caselle
RCSS	TSA	Taipei	Taiwan	Sungshan
ZBTJ	TSN	Tianjin	Peoples Republic of China	Binhai
KTUS	TUS	Tucson	USA Arizona	Tucson Intl
SEQU	UIO	Quito	Ecuador	Mariscal Sucre Intl
VTBU	UTP	Rayong	Thailand	U-Taphao Intl
SBKP	VCP	Campinas	Brazil	Viracopos Intl
KVCV	VCV	Victorville	USA California	Southern California Intl
LOWW	VIE	Vienna	Austria	Schwechat
LEVT	VIT	Vitoria	Spain	Foronda
NVVV	VLI	Port Vila	Vanuatu	Bauerfield
SLVR	VVI	Santa Cruz	Bolivia	Viru Viru Intl
UHWW	VVO	Vladivostok	Russia	Knevichi
OPNH	WNS	Nawabshah	Pakistan	Nawabshah
KWRI	WRI	Wrightstown	USA New Jersey	McGuire AFB
CYEG	YEG	Edmonton	Canada Alberta	Edmonton Intl
CYHZ	YHZ	Halifax	Canada Nova Scotia	Halifax Intl
KYIP	YIP	Detroit	USA Michigan	Willow Run
CYJT	YJT	Stephenville	Canada Newfoundland	Stephenville
CYMX	YMX	Montreal (Mirabel)	Canada Quebec	Montreal Intl (Mirabel)
CYOW	YOW	Ottawa	Canada Ontario	Ottawa / MacDonald-Cartier Intl
CYQX	YQX	Gander	Canada Newfoundland	Gander Intl
CYRB	YRB	Resolute Bay	Canada North West Terr.	Resolute Bay
CYUL	YUL	Montreal (Dorval)	Canada Quebec	Montreal Intl (Dorval)
CYVR	YVR	Vancouver	Canada British Columbia	Vancouver Intl
CYWG	YWG	Winnipeg	Canada Manatoba	Winnipeg Intl
CYYC	YYC	Calgary	Canada Alberta	Calgary Intl
CYYQ	YYQ	Churchill	Canada Manatoba	Churchill
CYYR	YYR	Goose Bay	Canada Newfoundland	Goose
CYYT	YYT	Saint Johns	Canada Newfoundland	St. Johns Intl
CYYZ	YYZ	Toronto	Canada Ontario	Toronto / Pearson Intl
LSZH	ZRH	Zurich	Switzerland	Zurich
OERY		Riyadh	Saudi Arabia	Riyadh AB
PHJR		Kapolei	USA Hawaii	Kalaeloa
SGCO		Concepcion	Paraguay	Ter. Crl. Carmelo Peralta

SORTED BY CITY NAME				
ICAO	IATA	City	Country	Airport
DIAP	ABJ	Abidjan	Ivory Coast	Felix Ho'uphouet-Boigny
OMAA	AUH	Abu Dhabi	U.A.E.	Abu Dhabi Intl
MMAA	ACA	Acapulco	Mexico	Gen Juan N. Alvarez Intl
DGAA	ACC	Accra	Ghana	Kotoka Intl
YPAD	ADL	Adelaide	Australia South Australia	Adelaide Intl
VAAH	AMD	Ahmedabad	India	Ahmedabad
OMAL	AAN	Al Ain	U.A.E.	Al Ain Intl
KABQ	ABQ	Albuquerque	USA New Mexico	Albuquerque Intl Sunport
YBAL	ASP	Alice Springs	Australia Northern Territory	Alice Springs
UAAA	ALA	Almaty	Kazakhstan	Almaty
KAMA	AMA	Amarillo	USA Texas	Amarillo Intl
OJAI	AMM	Amman	Jordan	Queen Alia Intl
EHAM	AMS	Amsterdam	Netherlands	Schiphol
PANC	ANC	Anchorage	USA Alaska	Anchorage Intl
PAED	EDF	Anchorage	USA Alaska	Elmendorf AFB
RPLC	CRK	Angeles - Clark	Philippines	Clark Intl.
LTAC	ESB	Ankara	Turkey	Esenboga
SCFA	ANF	Antofagasta	Chile	Cerro Moreno Intl
NSFA	APW	Apia	Western Samoa	Faleolo Intl
SPQU	AQP	Arequipa	Peru	Rodriguez Ballon
SGAS	ASU	Asuncion	Paraguay	Asuncion / Silvio Pettirossi Intl
HESN	ASW	Aswan	Egypt	Aswan
LGAT	ATH	Athens	Greece	Athens
KATL	ATL	Atlanta	USA Georgia	The Hartsfield Atlanta Intl
NZAA	AKL	Auckland	New Zealand	Auckland Intl
YMAV	AVV	Avalon	Australia Victoria	Avalon
OBBI	BAH	Bahrain	Bahrain	Bahrain Intl
MPHO	HOW	Balboa	Panama	Howard AFB
KBWI	BWI	Baltimore	USA Maryland	Baltimor Washington Intl
VOBG	BLR	Bangalore	India	Bangalore
VTBD	BKK	Bangkok	Thailand	Bangkok Intl
KBGR	BGR	Bangor	USA Maine	Bangor Intl
GBYD	BJL	Banjul	Gambia	Banjul Intl
TBPB	BGI	Barbados, Bridgetown	British West Indies	Grantley Adams Intl
LEBL	BCN	Barcelona	Spain	El Prat
SKBQ	BAQ	Barranquilla	Columbia	Ernesto Cortissoz
LFSB	BSL	Basle-Mulhouse	France	Basle-Mulhouse
ZBAA	PEK	Beijing	Peoples Republic of China	Capital
SBBE	BEL	Belem	Brazil	Val De Caes
EGAA	BFS	Belfast	United Kingdom	Aldergrove
SBCF	CNF	Belo Horizonte	Brazil	Tancredo Neves Intl
ENBR	BGO	Bergen	Norway	Flesland
TXKF	BDA	Bermuda	Bermuda Islands	Bermuda Intl
EKBI	BLL	Billund	Denmark	Billund
KBHM	BHM	Birmingham	USA Alabama	Birmingham Intl
EGBB	BHX	Birmingham	United Kingdom	Birmingham
FABL	BFN	Bloemfontein	South African Rep	Bloemfontein
LIPE	BLQ	Bologna	Italy	Borgo Panigale
KBOS	BOS	Boston	USA Massachusetts	Logan Intl
SBBR	BSB	Brasilia	Brazil	Pres Juscelino Kubitschek Intl
YBBN	BNE	Brisbane	Australia Queensland	Brisbane Intl
EBBR	BRU	Brussels	Belgium	Brussels Natl
SAEZ	EZE	Buenos Aires	Argentina	Ezeiza Intl. - Ministro Pistarini
KBUF	BUF	Buffalo	USA New York	Buffalo-Niagara Intl
YBCS	CNS	Cairns	Australia Queensland	Cairns Intl
HECA	CAI	Cairo	Egypt	Cairo Intl
VECC	CCU	Calcutta	India	Netaji Subhas Chandra Bose Intl
CYYC	YYC	Calgary	Canada Alberta	Calgary Intl
SKCL	CLO	Cali	Columbia	Alfonso Bonilla Aragon Intl
SBKP	VCP	Campinas	Brazil	Viracopos Intl
FACT	CPT	Cape Town	South African Rep	Cape Town Intl

SORTED BY CITY NAME				
ICAO	IATA	City	Country	Airport
LICZ	NSY	Catania	Italy	Signonella AB
KCHS	CHS	Charleston	USA South Carolina	Charleston AFB - Intl
LFLX	CHR	Chateauroux	France	Deols
RKPC	CJU	Cheju	Korea	Cheju Intl
VOMM	MAA	Chennai	India	Chennai Intl
VTCC	CNX	Chiang Mai	Thailand	Chiang Mai Intl
KORD	ORD	Chicago	USA Illinois	O'Hare Intl
NZCH	CHC	Christchurch	New Zealand	Christchurch Intl
CYYQ	YYQ	Churchill	Canada Manatoba	Churchill
KCVG	CVG	Cincinnati	USA Ohio	Cincinnati / Northern Kentucky Intl
SGES	AGT	Ciudad del Este	Paraguay	Guarani Intl
KCLE	CLE	Cleveland	USA Ohio	Hopkins Intl
PACD	CDB	Cold Bay	USA Alaska	Cold Bay
EDDK	CGN	Cologne-Bonn	Germany	Cologne-Bonn
VCBI	CMB	Colombo	Sri Lanka	Bandaranaike Intl
KLCK	LCK	Columbus	USA Ohio	Rickenbacker Intl
SGCO		Concepcion	Paraguay	Ter. Crl. Carmelo Peralta
EKCH	CPH	Copenhagen,	Denmark	Kastrup
SACO	COR	Cordoba	Argentina	Ing. A. L. V. Taravella Intl
TNCC	CUR	Curacao Island	Netherland Antilles	Hato Intl
SBCT	CWB	Curitiba	Brazil	Afonso Pena Intl
GOOY	DKR	Dakar	Senegal	Leopold Sedar Senghor
ZYTL	DLC	Dalian	Peoples Republic of China	Zhoushuizi
KDAL	DAL	Dallas	USA Texas	Dallas Love
KDFW	DFW	Dallas Fort Worth	USA Texas	Dallas Fort Worth Intl
OSDI	DAM	Damascus	Syria	Damascus Intl
OEDF	DMM	Dammam	Saudi Arabia	King Fahd Intl
HTDA	DAR	Dar-Es-Salaam	Tanzania	Dar-Es-Salaam Intl
YPDN	DRW	Darwin	Australia Northern Territory	Darwin Intl
VIDP	DEL	Delhi	India	Indira Gandhi Intl
KDEN	DEN	Denver	USA Colorado	Denver Intl
KDTW	DTW	Detroit	USA Michigan	Detroit Metro Wayne County
KYIP	YIP	Detroit	USA Michigan	Willow Run
OEDR	DHA	Dhahran	Saudi Arabia	King Abdulaziz AB
VGZR	DAC	Dhaka	Bangladesh	Zia Intl
OTBD	DOH	Doha	Qatar	Doha Intl
FKKD	DLA	Douala	Cameroon	Douala
KDOV	DOV	Dover	USA Delaware	Dover AFB
OMDB	DXB	Dubai	U.A.E.	Dubai Intl
EIDW	DUB	Dublin	Ireland	Dublin Intl
KDLH	DLH	Duluth	USA Minnesota	Duluth Intl
FADN	DUR	Durban	South African Rep	Durban Intl
EDDL	DUS	Dusseldorf	Germany	Dusseldorf
CYEG	YEG	Edmonton	Canada Alberta	Edmonton Intl
KELP	ELP	El Paso	USA Texas	El Paso Intl
KPAE	PAE	Everett	USA Washington	Snohomish Co.
PAEI	EIL	Fairbanks	USA Alaska	Eielson AFB
PAFA	FAI	Fairbanks	USA Alaska	Fairbanks Intl
KFLL	FLL	Fort Lauderdale	USA Florida	Hollywood Intl
EDDF	FRA	Frankfurt / Main	Germany	Frankfurt / Main
MYGF	FPO	Freeport	Bahamas	Freeport Intl
KFAT	FAT	Fresno	USA California	Fresno Yosemite Intl
OMFJ	FJR	Fujairah	UAE	Fujairah Intl
RJFF	FUK	Fukuoka	Japan	Fukuoka
FBSK	GBE	Gaborone	Botswana	Sir Seretse Khama Intl
CYQX	YQX	Gander	Canada Newfoundland	Gander Intl
LSGG	GVA	Geneva	Switzerland	Cointrin
LIMJ	GOA	Genoa	Italy	Sestri
EGPF	GLA	Glasgow	United Kingdom	Glasgow
CYYR	YJR	Goose Bay	Canada Newfoundland	Goose
ESGG	GOT	Goteborg	Sweden	Landvetter

SORTED BY CITY NAME				
ICAO	IATA	City	Country	Airport
GCLP	LPA	Gran Canaria	Canary Island	Gran Canaria
MMGL	GDL	Guadalajara	Mexico	Don Miguel Hidalgo Intl
ZGGG	CAN	Guangzhou	Peoples Republic of China	Baiyun
MUGM	NBW	Guantanamo Bay	Cuba	Guantanamo Bay NAS
MGGT	GUA	Guatemala City	Guatemala	La Aurora Intl
SEGU	GYE	Guayaquil	Equador	Simon Bolivar Intl
EDFH	HHN	Hahn	Germany	Hahn
RJCH	HKD	Hakodate	Japan	Hakodate
CYHZ	YHZ	Halifax	Canada Nova Scotia	Halifax Intl
EDDH	HAM	Hamburg	Germany	Hamburg
ZSHC	HGH	Hangzhou	Peoples Republic of China	Jiangqiao
EDDV	HAJ	Hannover	Germany	Hannover
FVHA	HRE	Harare	Zimbabwe	Harare Intl
EFHK	HEL	Helsinki	Finland	Vantaa
PHTO	ITO	Hilo	USA Hawaii	Hilo Intl
VHHH	HKG	Hong Kong	Peoples Republic of China	Hong Kong Intl
PHNL	HNL	Honolulu	USA Hawaii	Honolulu Intl
KIAH	IAH	Houston	USA Texas	George Bush Intercontinental / Houston
KHSV	HSV	Huntsville	USA Alabama	Huntsville Intl. - Jones
KIND	IND	Indianapolis	USA Indiana	Indianapolis Intl
LTBA	IST	Istanbul	Turkey	Ataturk
RJOI	IWA	Iwakuni	Japan	Iwakuni MCAS
KJAX	JAX	Jacksonville	USA Florida	Jacksonville Intl
WIII	CGK	Jakarta	Indonesia	Soekarno-Hatta Intl
WIIH	HLP	Jakarta-Halim	Indonesia	Halim Intl
OEJN	JED	Jeddah	Saudi Arabia	King Abdulaziz Intl
FAJS	JNB	Johannesburg	South African Rep	Johannesburg Intl
WMKJ	JHB	Johar Bahru	Malaysia	Sultan Ismail
SASJ	JUJ	Jujuy	Argentina	Gobernador Horacio Guzman
RJFK	KOJ	Kagoshima	Japan	Kagoshima
DNKN	KAN	Kano	Nigeria	Mallam Aminu Kano
KMCI	MCI	Kansas City	USA Missouri	Kansas City Intl
RCKH	KHH	Kaohsiung	Taiwan	Kaohsiung Intl
PHJR		Kapolei	USA Hawaii	Kalaeloa
OPKC	KHI	Karachi	Pakistan	Quaid-E-Azam Intl
BIKF	KEF	Keflavik	Iceland	Keflavik
UHHH	KHV	Khabarovsk	Russia	Khabarovsk Novy
HTKJ	JRO	Kilimanjaro	Tanzania	Kilimanjaro Intl
WBKK	BKI	Kota Kinabalu	Malaysia	Kota Kinabalu
WMKK	KUL	Kuala Lumpur	Malaysia	Kuala Lumpur Intl - Sepang
WMSA	SZB	Kuala Lumpur (old airport)	Malaysia	Sultan Abdul Aziz Shah-Subang Intl
WBGG	KCH	Kuching	Malaysia	Kuching Intl
RKJK	KUV	Kunsan	Korea	Kunsan AB
OKBK	KWI	Kuwait	Kuwait	Kuwait Intl
UKBB	KBP	Kyiv	Ukraine	Boryspil
DNMM	LOS	Lagos	Nigeria	Murtala Muhammed
OPLA	LHE	Lahore	Pakistan	Lahore Intl
LCLK	LCA	Larnaca	Cyprus	Larnaca Intl
KLAS	LAS	Las Vegas	USA Nevada	McCarran Intl
EBLG	LGG	Liege	Belgium	Liege
FWLI	LLW	Lilongwe	Malawi	Lilongwe Intl
SPIM	LIM	Lima-Callao	Peru	Jorge Chavez Intl
LOWL	LNZ	Linz	Austria	Linz
LPPT	LIS	Lisbon	Portugal	Lisbon
DXXX	LFW	Lome	Togo	Tokoin
EGKK	LGW	London-Gatwick	United Kingdom	Gatwick
EGLL	LHR	London-Heathrow	United Kingdom	Heathrow
EGSS	STN	London-Stansted	United Kingdom	Stansted
KLAX	LAX	Los Angeles	USA California	Los Angeles Intl
KSDF	SDF	Louisville	USA Kentucky	Louisville Intl - Standiford
FLLS	LUN	Lusaka	Zambia	Lusaka Intl

SORTED BY CITY NAME				
ICAO	IATA	City	Country	Airport
ELLX	LUX	Luxembourg	Luxembourg	Luxembourg
HELX	LXR	Luxor	Egypt	Luxor
EHBK	MST	Maastricht	Netherlands	Maastricht-Aachen
VMMC	MFM	Macau	Macau	Macau Intl
OEMA	MED	Madinah	Saudi Arabia	Prince Mohammad Bin Abdulaziz Intl
LEMD	MAD	Madrid	Spain	Barajas
LETO	TOJ	Madrid	Spain	Torrejon
FAMM	MBD	Mafikeng	South African Rep	Mafikeng Intl
UHMM	GDX	Magadan	Russia	Sokol
SVMI	CCS	Maiquetia - Caracas	Venezuela	Simon Bolivar Intl
ESMS	MMX	Malmo	Sweden	Sturup
SBEG	MAO	Manaus	Brazil	Eduardo Gomes Intl
EGCC	MAN	Manchester	United Kingdom	Manchester
RPLL	MNL	Manila	Philippines	Ninoy Aquino Intl
SEMT	MEC	Manta	Ecuador	Eloy Alfaro Intl
SVMC	MAR	Maracaibo	Venezuela	La Chinita Intl
KMZJ	MZJ	Marana	USA Arizona	Pinal Air Park
LFML	MRS	Marseille / Provence	France	Marseille / Provence
WIMM	MES	Medan	Indonesia	Polonia
YMML	MEL	Melbourne	Australia Victoria	Melbourne Intl
KMEM	MEM	Memphis	USA Tennessee	Memphis Intl
SAME	MDZ	Mendoza	Argentina	El Plumerillo
MMMX	MEX	Mexico City	Mexico	Lic Benito Juarez Intl
KMIA	MIA	Miami	USA Florida	Miami Intl
KMAF	MAF	Midland	USA Texas	Midland Intl
LIMC	MLX	Milan	Italy	Malpensa
KMKE	MKE	Milwaukee	USA Wisconsin	Gen. Mitchell Intl
KMSP	MSP	Minneapolis	USA Minnesota	Minneapolis-St Paul Intl
UMMS	MSQ	Minsk	Belarus	Minsk-2
RJSM	MSJ	Misawa	Japan	Misawa AB
KBFM	BFM	Mobile	USA Alabama	Mobile Downtown
HKMO	MBA	Mombasa	Kenya	Moi
SUMU	MVD	Montevideo	Uruguay	Carrasco Intl. / Gen Cesareo L. Berisso
CYUL	YUL	Montreal (Dorval)	Canada Quebec	Montreal Intl (Dorval)
CYMX	YMX	Montreal (Mirabel)	Canada Quebec	Montreal Intl (Mirabel)
UUEE	SVO	Moscow	Russia	Sheremetyevo
VABB	BOM	Mumbai	India	Chhatrapati Shivaji Intl
EDDM	MUC	Munich	Germany	Munich
OOMS	MCT	Muscat	Oman	Seeb Intl
NFFN	NAN	Nadi	Fiji Islands	Nadi Intl
RJFU	NGS	Nagasaki	Japan	Nagasaki
RJNN	NGO	Nagoya	Japan	Nagoya
ROAH	OKA	Naha, Okinawa	Japan	Naha
HKJK	NBO	Nairobi	Kenya	Jomo Kenyatta
MYNN	NAS	Nassau	Bahamas	Nassau Intl
OPNH	WNS	Nawabshah	Pakistan	Nawabshah
KMSY	MSY	New Orleans	USA Louisiana	New Orleans Intl
KJFK	JFK	New York	USA New York	Kennedy Intl
KEWR	EWR	Newark	USA New Jersey	Newark Intl
KSWF	SWF	Newburgh	USA New York	Stewart Intl
KIAG	IAG	Niagara Falls	USA New York	Niagara Falls Intl
LFMN	NCE	Nice / Cote D'Azur	France	Nice / Cote D'Azur
KNGU	NGU	Norfolk	USA Virginia	Norfolk NAS
KORF	ORF	Norfolk	USA Virginia	Norfolk Intl
GQNN	NKC	Nouakchott	Mauritania	Nouakchott
NWWW	NOU	Noumea	New Caledonia	Tontouta
NFTF	TBU	Nuku'alofa	Tonga	Fua'amotu Intl
KOAK	OAK	Oakland	USA California	Metro Oakland Intl
RODN	DNA	Okinawa Island	Japan	Kadena AB
KOKC	OKC	Oklahoma City	USA Oklahoma	Will Rogers World
KOMA	OMA	Omaha	USA Nebraska	Eppley

SORTED BY CITY NAME				
ICAO	IATA	City	Country	Airport
KONT	ONT	Ontario	USA California	Ontario Intl
KMCO	MCO	Orlando	USA Florida	Orlando Intl
RJOO	ITM	Osaka	Japan	Osaka Intl
RJBB	KIX	Osaka	Japan	Kansai Intl
RKSO	OSN	Osan	Korea	Osan AB
ENGM	GEN	Oslo	Norway	Gardermoen
EBOS	OST	Ostend	Belgium	Ostend
CYOW	YOW	Ottawa	Canada Ontario	Ottawa / MacDonald-Cartier Intl
NSTU	PPG	Pago Pago	American Samoa	Pago Pago Intl
KPMD	PMD	Palmdale	USA California	Palmdale AF Plant 42
MPTO	PTY	Panama City	Panama	Tocumen Intl
LFPG	CDG	Paris	France	Charles de Gaulle
LFPO	ORY	Paris	France	Orly
WMKP	PEN	Penang Island	Malaysia	Penang Intl
YPPH	PER	Perth	Australia Western Aust.	Perth Intl
UHPP	PCK	Petropavlovsk Kamchatsky	Russia	Yelizovo
KPHL	PHL	Philadelphia	USA Pennsylvania	Philadelphia Intl
KPHX	PHX	Phoenix	USA Arizona	Phoenix Sky Harbor Intl
VTSP	HKT	Phuket	Thailand	Phuket Intl
LIRP	PSA	Pisa	Italy	San Giusto
SPSO	PIO	Pisco	Peru	Pisco
KPIT	PIT	Pittsburgh	USA Pennsylvania	Pittsburgh Intl
DNPO	PHC	Port Harcourt	Nigeria	Port Harcourt
TTPP	POS	Port of Spain	Trinidad	Piarco Intl
NVVV	VLI	Port Vila	Vanuatu	Bauerfield
KPDX	PDX	Portland	USA Oregon	Portland Intl
LPPR	OPO	Porto	Portugal	Francisco' Sa Carneiro
SBPA	POA	Porto Alegre	Brazil	Salgado Filho Intl
KPSM	PSM	Portsmouth	USA, New Hampshire	Pease Intl Tradeport
EGPK	PIK	Prestwick	United Kingdom	Prestwick
SEQU	UIO	Quito	Ecuador	Mariscal Sucre Intl
ETAR	RMS	Ramstein	Germany	Ramstein AB
OMRK	RKT	Ras Al Khaimah	U.A.E.	Ras Al Khaimah Intl
VTBU	UTP	Rayong	Thailand	U-Taphao Intl
SBRF	REC	Recife	Brazil	Guararapes Intl
CYRB	YRB	Resolute Bay	Canada North West Terr.	Resolute Bay
LGRP	RHO	Rhodos	Greece	Diagoras
SBGL	GIG	Rio De Janeiro	Brazil	Galeao Antonio Carlos Jobin Intl
SKRG	MDE	Rionegro	Columbia	Jose Maria Cordova
OERK	RUH	Riyadh	Saudi Arabia	King Khalid Intl
OERY		Riyadh	Saudi Arabia	Riyadh AB
LIRA	CIA	Rome	Italy	Ciampino
LIRF	FCO	Rome	Italy	Fiumicino
SAAR	ROS	Rosario	Argentina	Rosario
LERT	RTA	Rota	Spain	Rota Navy
CYYT	YYT	Saint Johns	Canada Newfoundland	St. Johns Intl
KSTL	STL	Saint Louis	USA Missouri	Lambert - Saint Louis Intl
ULLI	LED	Saint Petersburg	Russia	Pulkovo
GVAC	SID	Sal	Cape Verdi	Amilcar Cabral
SBSV	SSA	Salvador	Brazil	Dep. L.E. Magal'haes Intl
KSAT	SAT	San Antonio	USA Texas	San Antonio Intl
KSAN	SAN	San Diego	USA California	San Diego Intl - Lindbergh
KSFO	SFO	San Franscisco	USA California	San Franscisco Intl
MROC	SJO	San Jose	Costa Rica	Alajuela (Juan Santamaria Intl)
TJSJ	SJU	San Juan	Puerto Rico	Luis Munoz Marin Intl
MSLP	SAL	San Salvador	El Salvador	El Salvador Intl
SLVR	VVI	Santa Cruz	Bolivia	Viru Viru Intl
SKBO	BOG	Santafe De Bogota	Columbia	Eldorado Intl
SBSN	STM	Santarem	Brazil	Santarem Intl
SECL	SCL	Santiago	Chile	Arturo Merino Benitez Intl
MDSO	SDQ	Santo Domingo	Dominican Republic	Las Americas Intl

SORTED BY CITY NAME				
ICAO	IATA	City	Country	Airport
SBGR	GRU	Sao Paulo	Brazil	Sao Paulo / Intl - Guarulhos
RJCC	CTS	Sapporo	Japan	New Chitose
RJCJ	OKD	Sapporo	Japan	Chitose
KSAV	SAV	Savannah	USA Georgia	Savannah Intl
KBFI	BFI	Seattle	USA Washington	Boeing Field / King Co. Intl
KSEA	SEA	Seattle	USA Washington	Seattle - Tacoma Intl
RJSS	SDJ	Sendai	Japan	Sendai
RKSS	SEL	Seoul	Korea	Kimpo Intl
LEZL	SVQ	Seville	Spain	San Pablo
ZSSS	SHA	Shanghai	Peoples Republic of China	Hongqiao
ZSPD	PVG	Shanghai	Peoples Republic of China	Pudong
EINN	SNN	Shannon	Ireland	Shannon
OMSJ	SHJ	Sharjah	U.A.E	Sharjah Intl
PASY	SYA	Shemya	USA Alaska	Eareckson AS
ZGSZ	SZX	Shenzhen	Peoples Republic of China	Huangtian
WSAP	QPG	Singapore	Singapore	Paya Lebar Aero
WSSS	SIN	Singapore	Singapore	Changi
LWSK	SKP	Skopje	Macedonia	Skopje
BGSF	SFJ	Sondre Stromfjord	Greenland	Kangerlussuaq
ENZV	SVG	Stavanger	Norway	Sola
CYJT	YJT	Stephenville	Canada Newfoundland	Stephenville
ESSA	ARN	Stockholm	Sweden	Arlanda
EDDS	STR	Stuttgart	Germany	Stuttgart
RPLB	SFS	Subic Bay	Philippines	Subic Bay Intl
WRSJ	SUB	Surabaya	Indonesia	Juanda
YSSY	SYD	Sydney	Australia NewSouthWales	Kingford Smith Intl
RCTP	TPE	Taipei	Taiwan	Chiang Kai Shek Intl
RCSS	TSA	Taipei	Taiwan	Sungshan
KTPA	TPA	Tampa	USA Florida	Tampa Intl
UTTT	TAS	Tashkent	Uzbekistan	Yuzhny
UGGG	TBS	Tbilisi	Georgia	Lochini
LLBG	TLV	Tel Aviv	Isreal	Ben Gurion
GCXO	TFN	Tenerife North	Canary Island	Los Rodeos
GCTS	TFS	Tenerife South	Canary Island	Reina Sofia
LGTS	SKG	Thessaloniki	Greece	Makedonia
BGTL	THU	Thule	Greenland	Thule AB
ZBTJ	TSN	Tianjin	Peoples Republic of China	Binhai
RJTT	HND	Tokyo Haneda	Japan	Tokyo Intl
RJAA	NRT	Tokyo Narita	Japan	Narita (New Tokyo Intl)
RJTY	OKO	Tokyo Yokota	Japan	Yokota AB
KTOL	TOL	Toledo	USA Ohio	Toledo Express
LIMF	TRN	Torino	Italy	Caselle
CYYZ	YYZ	Toronto	Canada Ontario	Toronto / Pearson Intl
LFBO	TLS	Toulouse	France	Blagnac
KTUS	TUS	Tucson	USA Arizona	Tucson Intl
EFTU	TKU	Turku	Finland	Turku
CYVR	YVR	Vancouver	Canada British Columbia	Vancouver Intl
KVCV	VCV	Victorville	USA California	Southern California Intl
LOWW	VIE	Vienna	Austria	Schwechat
LEVT	VIT	Vitoria	Spain	Foronda
UHWV	VVO	Vladivostok	Russia	Knevichi
KIAD	IAD	Washington D.C.	USA D. C.	Washington Dulles Intl
KIAB	IAB	Wichita	USA Kansas	McConnell AFB
KICT	ICT	Wichita	USA Kansas	Wichita Mid - Continent
KBDL	BDL	Windsor Locks	USA Connecticut	Bradley Intl
CYWG	YWG	Winnipeg	Canada Manatoba	Winnipeg Intl
KWRI	WRI	Wrightstown	USA New Jersey	McGuire AFB
SMJP	PBM	Zandery	Suriname	J. A. Pengel Intl
LSZH	ZRH	Zurich	Switzerland	Zurich

SORTED BY COUNTRY NAME				
ICAO	IATA	City	Country	Airport
NSTU	PPG	Pago Pago	American Samoa	Pago Pago Intl
SAEZ	EZE	Buenos Aires	Argentina	Ezeiza Intl. - Ministro Pistarini
SACO	COR	Cordoba	Argentina	Ing. A. L. V. Taravella Intl
SASJ	JUJ	Jujuy	Argentina	Gobernador Horacio Guzman
SAME	MDZ	Mendoza	Argentina	El Plumerillo
SAAR	ROS	Rosario	Argentina	Rosario
YSSY	SYD	Sydney	Australia NewSouthWales	Kingford Smith Intl
YBAL	ASP	Alice Springs	Australia NorthernTerritory	Alice Springs
YPDN	DRW	Darwin	Australia NorthernTerritory	Darwin Intl
YBBN	BNE	Brisbane	Australia Queensland	Brisbane Intl
YBCS	CNS	Cairns	Australia Queensland	Cairns Intl
YPAD	ADL	Adelaide	Australia South Australia	Adelaide Intl
YMAV	AVV	Avalon	Australia Victoria	Avalon
YMML	MEL	Melbourne	Australia Victoria	Melbourne Intl
YPPH	PER	Perth	Australia Western Aust.	Perth Intl
LOWL	LNZ	Linz	Austria	Linz
LOWW	VIE	Vienna	Austria	Schwechat
MYGF	FPO	Freeport	Bahamas	Freeport Intl
MYNN	NAS	Nassau	Bahamas	Nassau Intl
OBBI	BAH	Bahrain	Bahrain	Bahrain Intl
VGZR	DAC	Dhaka	Bangladesh	Zia Intl
UMMS	MSQ	Minsk	Belarus	Minsk-2
EBBR	BRU	Brussels	Belgium	Brussels Natl
EBLG	LGG	Liege	Belgium	Liege
EBOS	OST	Ostend	Belgium	Ostend
TXKF	BDA	Bermuda	Bermuda Islands	Bermuda Intl
SLVR	VVI	Santa Cruz	Bolivia	Viru Viru Intl
FBSK	GBE	Gaborone	Botswana	Sir Seretse Khama Intl
SBBE	BEL	Belem	Brazil	Val De Caes
SBCF	CNF	Belo Horizonte	Brazil	Tancredo Neves Intl
SBBR	BSB	Brasilia	Brazil	Pres Juscelino Kubitschek Intl
SBKP	VCP	Campinas	Brazil	Viracopos Intl
SBCT	CWB	Curitiba	Brazil	Afonso Pena Intl
SBEG	MAO	Manaus	Brazil	Eduardo Gomes Intl
SBPA	POA	Porto Alegre	Brazil	Salgado Filho Intl
SBRF	REC	Recife	Brazil	Guararapes Intl
SBGL	GIG	Rio De Janeiro	Brazil	Galeao Antonio Cartos Jobin Intl
SBSV	SSA	Salvador	Brazil	Dep. L.E. Magal'haes Intl
SBSN	STM	Santarem	Brazil	Santarem Intl
SBGR	GRU	Sao Paulo	Brazil	Sao Paulo / Intl - Guarulhos
TBPB	BGI	Barbados, Bridgetown	British West Indies	Grantley Adams Intl
FKKD	DLA	Douala	Cameroon	Douala
CYYC	YYC	Calgary	Canada Alberta	Calgary Intl
CYEG	YEG	Edmonton	Canada Alberta	Edmonton Intl
CYVR	YVR	Vancouver	Canada British Columbia	Vancouver Intl
CYYQ	YYQ	Churchill	Canada Manatoba	Churchill
CYWG	YWG	Winnipeg	Canada Manatoba	Winnipeg Intl
CYQX	YQX	Gander	Canada Newfoundland	Gander Intl
CYYR	YYR	Goose Bay	Canada Newfoundland	Goose
CYYT	YYT	Saint Johns	Canada Newfoundland	St. Johns Intl
CYJT	YJT	Stephenville	Canada Newfoundland	Stephenville
CYRB	YRB	Resolute Bay	Canada North West Terr.	Resolute Bay
CYHZ	YHZ	Halifax	Canada Nova Scotia	Halifax Intl
CYOW	YOW	Ottawa	Canada Ontario	Ottawa / MacDonald-Cartier Intl
CYYZ	YYZ	Toronto	Canada Ontario	Toronto / Pearson Intl
CYUL	YUL	Montreal (Dorval)	Canada Quebec	Montreal Intl (Dorval)
CYMX	YMX	Montreal (Mirabel)	Canada Quebec	Montreal Intl (Mirabel)
GCLP	LPA	Gran Canaria	Canary Island	Gran Canaria
GCXO	TFN	Tenerife North	Canary Island	Los Rodeos
GCTS	TFS	Tenerife South	Canary Island	Reina Sofia
GVAC	SID	Sal	Cape Verdi	Amilcar Cabral

SORTED BY COUNTRY NAME				
ICAO	IATA	City	Country	Airport
SCFA	ANF	Antofagasta	Chile	Cerro Moreno Intl
SCEL	SCL	Santiago	Chile	Arturo Merino Benitez Intl
SKBQ	BAQ	Barranquilla	Columbia	Ernesto Cortissoz
SKCL	CLO	Cali	Columbia	Alfonso Bonilla Aragon Intl
SKRG	MDE	Rionegro	Columbia	Jose Maria Cordova
SKBO	BOG	Santafe De Bogota	Columbia	Eldorado Intl
MROC	SJO	San Jose	Costa Rica	Alajuela (Juan Santamaria Intl)
MUGM	NBW	Guantanamo Bay	Cuba	Guantanamo Bay NAS
LCLK	LCA	Lamaca	Cyprus	Lamaca Intl
EKBI	BLL	Billund	Denmark	Billund
EKCH	CPH	Copenhagen,	Denmark	Kastrup
MDSD	SDQ	Santo Domingo	Dominican Republic	Las Americas Intl
SEQU	UIO	Quito	Ecuador	Mariscal Sucre Intl
HESN	ASW	Aswan	Egypt	Aswan
HECA	CAI	Cairo	Egypt	Cairo Intl
HELX	LXR	Luxor	Egypt	Luxor
MSLP	SAL	San Salvador	El Salvador	El Salvador Intl
SEGU	GYE	Guayaquil	Equador	Simon Bolivar Intl
SEMT	MEC	Manta	Equador	Eloy Alfaro Intl
NFFN	NAN	Nadi	Fiji Islands	Nadi Intl
EFHK	HEL	Helsinki	Finland	Vantaa
EFTU	TKU	Turku	Finland	Turku
LFSB	BSL	Basle-Mulhouse	France	Basle-Mulhouse
LFLX	CHR	Chateauroux	France	Deols
LFML	MRS	Marseille / Provence	France	Marseille / Provence
LFMN	NCE	Nice / Cote D'Azur	France	Nice / Cote D'Azur
LFPG	CDG	Paris	France	Charles de Gaulle
LFPO	ORY	Paris	France	Orly
LFBO	TLS	Toulouse	France	Blagnac
GBYD	BJL	Banjul	Gambia	Banjul Intl
UGGG	TBS	Tbilisi	Georgia	Lochini
EDDK	CGN	Cologne-Bonn	Germany	Cologne-Bonn
EDDL	DUS	Dusseldorf	Germany	Dusseldorf
EDDF	FRA	Frankfurt / Main	Germany	Frankfurt / Main
EDFH	HHN	Hahn	Germany	Hahn
EDDH	HAM	Hamburg	Germany	Hamburg
EDDV	HAJ	Hannover	Germany	Hannover
EDDM	MUC	Munich	Germany	Munich
ETAR	RMS	Ramstein	Germany	Ramstein AB
EDDS	STR	Stuttgart	Germany	Stuttgart
DGAA	ACC	Accra	Ghana	Kotoka Intl
LGAT	ATH	Athens	Greece	Athens
LGRP	RHO	Rhodos	Greece	Diagoras
LGTS	SKG	Thessaloniki	Greece	Makedonia
BGSF	SFJ	Sondre Stromfjord	Greenland	Kangerlussuaq
BGTL	THU	Thule	Greenland	Thule AB
MGGT	GUA	Guatemala City	Guatemala	La Aurora Intl
BIKF	KEF	Keflavik	Iceland	Keflavik
VAAH	AMD	Ahmedabad	India	Ahmedabad
VOBG	BLR	Bangalore	India	Bangalore
VECC	CCU	Calcutta	India	Netaji Subhas Chandra Bose Intl
VOMM	MAA	Chennai	India	Chennai Intl
VIDP	DEL	Delhi	India	Indira Gandhi Intl
VABB	BOM	Mumbai	India	Chhatrapati Shivaji Intl
WIII	CGK	Jakarta	Indonesia	Soekarno-Hatta Intl
WIIH	HLP	Jakarta-Halim	Indonesia	Halim Intl
WIMM	MES	Medan	Indonesia	Polonia
WRSJ	SUB	Surabaya	Indonesia	Juanda
EIDW	DUB	Dublin	Ireland	Dublin Intl
EINN	SNN	Shannon	Ireland	Shannon
LLBG	TLV	Tel Aviv	Isreal	Ben Gurion

SORTED BY COUNTRY NAME				
ICAO	IATA	City	Country	Airport
LIPE	BLQ	Bologna	Italy	Borgo Panigale
LICZ	NSY	Catania	Italy	Signonella AB
LIMJ	GOA	Genoa	Italy	Sestri
LIMC	MXP	Milan	Italy	Malpensa
LIRP	PSA	Pisa	Italy	San Giusto
LIRA	CIA	Rome	Italy	Ciampino
LIRF	FCO	Rome	Italy	Fiumicino
LIMF	TRN	Torino	Italy	Caselle
DIAP	ABJ	Abidjan	Ivory Coast	Felix Ho'uphouet-Boigny
RJFF	FUK	Fukuoka	Japan	Fukuoka
RJCH	HKD	Hakodate	Japan	Hakodate
RJOI	IWA	Iwakuni	Japan	Iwakuni MCAS
RJFK	KOJ	Kagoshima	Japan	Kagoshima
RJSM	MSJ	Misawa	Japan	Misawa AB
RJFU	NGS	Nagasaki	Japan	Nagasaki
RJNN	NGO	Nagoya	Japan	Nagoya
ROAH	OKA	Naha, Okinawa	Japan	Naha
RODN	DNA	Okinawa Island	Japan	Kadena AB
RJOO	ITM	Osaka	Japan	Osaka Intl
RJBB	KIX	Osaka	Japan	Kansai Intl
RJCC	CTS	Sapporo	Japan	New Chitose
RJCJ	OKD	Sapporo	Japan	Chitose
RJSS	SDJ	Sendai	Japan	Sendai
RJTT	HND	Tokyo Haneda	Japan	Tokyo Intl
RJAA	NRT	Tokyo Narita	Japan	(Narita) New Tokyo Intl
RJTY	OKO	Tokyo Yokota	Japan	Yokota AB
OJAI	AMM	Amman	Jordan	Queen Alia Intl
UAAA	ALA	Almaty	Kazakhstan	Almaty
HKMO	MBA	Mombasa	Kenya	Moi
HKJK	NBO	Nairobi	Kenya	Jomo Kenyatta
RKPC	CJU	Cheju	Korea	Cheju Intl
RKJK	KUV	Kunsan	Korea	Kunsan AB
RKSO	OSN	Osan	Korea	Osan AB
RKSS	SEL	Seoul	Korea	Kimpo Intl
OKBK	KWI	Kuwait	Kuwait	Kuwait Intl
ELLX	LUX	Luxembourg	Luxembourg	Luxembourg
VMMC	MFM	Macau	Macau	Macau Intl
LWSK	SKP	Skopje	Macedonia	Skopje
FWLI	LLW	Lilongwe	Malawi	Lilongwe Intl
WMKJ	JHB	Johar Bahru	Malaysia	Sultan Ismail
WBKK	BKI	Kota Kinabalu	Malaysia	Kota Kinabalu
WMKK	KUL	Kuala Lumpur	Malaysia	Kuala Lumpur Intl - Sepang
WMSA	SZB	Kuala Lumpur (old airport)	Malaysia	Sultan Abdul Aziz Shah-Subang Intl
WBGG	KCH	Kuching	Malaysia	Kuching Intl
WMKP	PEN	Penang Island	Malaysia	Penang Intl
GQNN	NKC	Nouakchott	Mauritania	Nouakchott
MMAA	ACA	Acapulco	Mexico	Gen Juan N. Alvarez Intl
MMGL	GDL	Guadalajara	Mexico	Don Miguel Hidalgo Intl
MMM	MEX	Mexico City	Mexico	Lic Benito Juarez Intl
TNCC	CUR	Curacao Island	Netherland Antilles	Hato Intl
EHAM	AMS	Amsterdam	Netherlands	Schiphol
EHBK	MST	Maastricht	Netherlands	Maastricht-Aachen
NWWW	NOU	Noumea	New Caledonia	Tontouta
NZAA	AKL	Auckland	New Zealand	Auckland Intl
NZCH	CHC	Christchurch	New Zealand	Christchurch Intl
DNKN	KAN	Kano	Nigeria	Mallam Aminu Kano
DNMM	LOS	Lagos	Nigeria	Murtala Muhammed
DNPO	PHC	Port Harcourt	Nigeria	Port Harcourt
ENBR	BGO	Bergen	Norway	Flesland
ENGM	GEN	Oslo	Norway	Gardermoen
ENZV	SVG	Stavanger	Norway	Sola

SORTED BY COUNTRY NAME				
ICAO	IATA	City	Country	Airport
OOMS	MCT	Muscat	Oman	Seeb Intl
OPKC	KHI	Karachi	Pakistan	Quaid-E-Azam Intl
OPLA	LHE	Lahore	Pakistan	Lahore Intl
OPNH	WNS	Nawabshah	Pakistan	Nawabshah
MPHO	HOW	Balboa	Panama	Howard AFB
MPTO	PTY	Panama City	Panama	Tocumen Intl
SGAS	ASU	Asuncion	Paraguay	Asuncion / Silvio Pettrossi Intl
SGES	AGT	Ciudad del Este	Paraguay	Guarani Intl
SGCO		Concepcion	Paraguay	Ter. CrI. Carmelo Peralta
ZBAA	PEK	Beijing	Peoples Republic of China	Capital
ZYTL	DLC	Dalian	Peoples Republic of China	Zhoushuizi
ZGGG	CAN	Guangzhou	Peoples Republic of China	Baiyun
ZSHC	HGH	Hangzhou	Peoples Republic of China	Jiangqiao
VHHH	HKG	Hong Kong	Peoples Republic of China	Hong Kong Intl
ZSSS	SHA	Shanghai	Peoples Republic of China	Hongqiao
ZSPD	PVG	Shanghai	Peoples Republic of China	Pudong
ZGSZ	SZX	Shenzhen	Peoples Republic of China	Huangtian
ZBTJ	TSN	Tianjin	Peoples Republic of China	Binhai
SPQU	AQP	Arequipa	Peru	Rodriguez Ballon
SPIM	LIM	Lima-Callao	Peru	Jorge Chavez Intl
SPSO	PIO	Pisco	Peru	Pisco
RPLC	CRK	Angeles - Clark	Philippines	Clark Intl.
RPLL	MNL	Manila	Philippines	Ninoy Aquino Intl
RPLB	SFS	Subic Bay	Philippines	Subic Bay Intl
LPPT	LIS	Lisbon	Portugal	Lisbon
LPPR	OPO	Porto	Portugal	Francisco' Sa Carneiro
TJSJ	SJU	San Juan	Puerto Rico	Luis Munoz Marin Intl
OTBD	DOH	Doha	Qatar	Doha Intl
UHHH	KHV	Khabarovsk	Russia	Khabarovsk Novy
UHMM	GDX	Magadan	Russia	Sokol
UUEE	SVO	Moscow	Russia	Sheremetyevo
UHPP	PCK	Petropavlovsk Kamchatsky	Russia	Yelizovo
ULLI	LED	Saint Petersburg	Russia	Pulkovo
UHWV	VVO	Vladivostok	Russia	Knevichi
OEDF	DMM	Dammam	Saudi Arabia	King Fahd Intl
OEDR	DHA	Dhahran	Saudi Arabia	King Abdulaziz AB
OEJN	JED	Jeddah	Saudi Arabia	King Abdulaziz Intl
OEMA	MED	Madinah	Saudi Arabia	Prince Mohammad Bin Abdulaziz Intl
OERK	RUH	Riyadh	Saudi Arabia	King Khalid Intl
OERY		Riyadh	Saudi Arabia	Riyadh AB
GOOY	DKR	Dakar	Senegal	Leopold Sedar Senghor
WSAP	QPG	Singapore	Singapore	Paya Lebar Aero
WSSS	SIN	Singapore	Singapore	Changi
FABL	BFN	Bloemfontein	South African Rep	Bloemfontein
FACT	CPT	Cape Town	South African Rep	Cape Town Intl
FADN	DUR	Durban	South African Rep	Durban Intl
FAJS	JNB	Johannesburg	South African Rep	Johannesburg Intl
FAMM	MBD	Mafikeng	South African Rep	Mafikeng Intl
LEBL	BCN	Barcelona	Spain	El Prat
LEMD	MAD	Madrid	Spain	Barajas
LETO	TOJ	Madrid	Spain	Torrejon
LERT	RTA	Rota	Spain	Rota Navy
LEZL	SVQ	Seville	Spain	San Pablo
LEVT	VIT	Vitoria	Spain	Foronda
VCBI	CMB	Colombo	Sri Lanka	Bandaranaike Intl
SMJP	PBM	Zandery	Suriname	J. A. Pengel Intl
ESGG	GOT	Goteborg	Sweden	Landvetter
ESMS	MMX	Malmo	Sweden	Sturup
ESSA	ARN	Stockholm	Sweden	Arlanda
LSGG	GVA	Geneva	Switzerland	Cointrin
LSZH	ZRH	Zurich	Switzerland	Zurich

SORTED BY COUNTRY NAME

ICAO	IATA	City	Country	Airport
OSDI	DAM	Damascus	Syria	Damascus Intl
RCKH	KHH	Kaohsiung	Taiwan	Kaohsiung Intl
RCTP	TPE	Taipei	Taiwan	Chiang Kai Shek Intl
RCSS	TSA	Taipei	Taiwan	Sungshan
HTDA	DAR	Dar-Es-Salaam	Tanzania	Dar-Es-Salaam Intl
HTKJ	JRO	Kilimanjaro	Tanzania	Kilimanjaro Intl
VTBD	BKK	Bangkok	Thailand	Bangkok Intl
VTCC	CNX	Chiang Mai	Thailand	Chiang Mai Intl
VTSP	HKT	Phuket	Thailand	Phuket Intl
VTBU	UTP	Rayong	Thailand	U-Taphao Intl
DXXX	LFW	Lome	Togo	Tokoin
NFTF	TBU	Nuku'alofa	Tonga	Fua'amotu Intl
TTPP	POS	Port of Spain	Trinidad	Piarco Intl
LTAC	ESB	Ankara	Turkey	Esenboga
LTBA	IST	Istanbul	Turkey	Ataturk
OMSJ	SHJ	Sharjah	U.A.E	Sharjah Intl
OMAA	AUH	Abu Dhabi	U.A.E.	Abu Dhabi Intl
OMAL	AAN	Al Ain	U.A.E.	Al Ain Intl
OMDB	DXB	Dubai	U.A.E.	Dubai Intl
OMRK	RKT	Ras Al Khaimah	U.A.E.	Ras Al Khaimah Intl
OMFJ	FJR	Fujairah	UAE	Fujairah Intl
UKBB	KBP	Kyiv	Ukraine	Boryspil
EGAA	BFS	Belfast	United Kingdom	Aldergrove
EGBB	BHX	Birmingham	United Kingdom	Birmingham
EGPF	GLA	Glasgow	United Kingdom	Glasgow
EGKK	LGW	London-Gatwick	United Kingdom	Gatwick
EGLL	LHR	London-Heathrow	United Kingdom	Heathrow
EGSS	STN	London-Stansted	United Kingdom	Stansted
EGCC	MAN	Manchester	United Kingdom	Manchester
EGPK	PIK	Prestwick	United Kingdom	Prestwick
SUMU	MVD	Montevideo	Uruguay	Carrasco Intl. / Gen Cesareo L. Berisso
KBHM	BHM	Birmingham	USA Alabama	Birmingham Intl
KHSV	HSV	Huntsville	USA Alabama	Huntsville Intl. - Jones
KBFM	BFM	Mobile	USA Alabama	Mobile Downtown
PANC	ANC	Anchorage	USA Alaska	Anchorage Intl
PAED	EDF	Anchorage	USA Alaska	Elmendorf AFB
PACD	CDB	Cold Bay	USA Alaska	Cold Bay
PAEI	EIL	Fairbanks	USA Alaska	Eielson AFB
PAFA	FAI	Fairbanks	USA Alaska	Fairbanks Intl
PASY	SYA	Shemya	USA Alaska	Eareckson AS
KMZJ	MZJ	Marana	USA Arizona	Pinal Air Park
KPHX	PHX	Phoenix	USA Arizona	Phoenix Sky Harbor Intl
KTUS	TUS	Tucson	USA Arizona	Tucson Intl
KFAT	FAT	Fresno	USA California	Fresno Yosemite Intl
KLAX	LAX	Los Angeles	USA California	Los Angeles Intl
KOAK	OAK	Oakland	USA California	Metro Oakland Intl
KONT	ONT	Ontario	USA California	Ontario Intl
KPMD	PMD	Palmdale	USA California	Palmdale AF Plant 42
KSAN	SAN	San Diego	USA California	San Diego Intl - Lindbergh
KSFO	SFO	San Fransciso	USA California	San Fransciso Intl
KVCV	VCV	Victorville	USA California	Southern California Intl
KDEN	DEN	Denver	USA Colorado	Denver Intl
KBDL	BDL	Windsor Locks	USA Connecticut	Bradley Intl
KIAD	IAD	Washington D.C.	USA D. C.	Washington Dulles Intl
KDOV	DOV	Dover	USA Deleware	Dover AFB
KFLL	FLL	Fort Lauderdale	USA Florida	Hollywood Intl
KJAX	JAX	Jacksonville	USA Florida	Jacksonville Intl
KMIA	MIA	Miami	USA Florida	Miami Intl
KMCO	MCO	Orlando	USA Florida	Orlando Intl
KTPA	TPA	Tampa	USA Florida	Tampa Intl
KATL	ATL	Atlanta	USA Georgia	The Hartsfield Atlanta Intl

SORTED BY COUNTRY NAME				
ICAO	IATA	City	Country	Airport
KSAV	SAV	Savannah	USA Georgia	Savannah Intl
PHTO	ITO	Hilo	USA Hawaii	Hilo Intl
PHNL	HNL	Honolulu	USA Hawaii	Honolulu Intl
PHJR		Kapolei	USA Hawaii	Kalaeloa
KORD	ORD	Chicago	USA Illinois	O'Hare Intl
KIND	IND	Indianapolis	USA Indiana	Indianapolis Intl
KIAB	IAB	Wichita	USA Kansas	McConnell AFB
KICT	ICT	Wichita	USA Kansas	Wichita Mid - Continent
KSDF	SDF	Louisville	USA Kentucky	Louisville Intl - Standiford
KMSY	MSY	New Orleans	USA Louisiana	New Orleans Intl
KBGR	BGR	Bangor	USA Maine	Bangor Intl
KBWI	BWI	Baltimore	USA Maryland	Baltimor Washington Intl
KBOS	BOS	Boston	USA Massachusetts	Logan Intl
KDTW	DTW	Detroit	USA Michigan	Detroit Metro Wayne County
KYIP	YIP	Detroit	USA Michigan	Willow Run
KDLH	DLH	Duluth	USA Minnesota	Duluth Intl
KMSP	MSP	Minneapolis	USA Minnesota	Minneapolis-St Paul Intl
KMCI	MCI	Kansas City	USA Missouri	Kansas City Intl
KSTL	STL	Saint Louis	USA Missouri	Lambert - Saint Louis Intl
KOMA	OMA	Omaha	USA Nebraska	Eppley
KLAS	LAS	Las Vegas	USA Nevada	McCarran Intl
KEWR	EWR	Newark	USA New Jersey	Newark Intl
KWRI	WRI	Wrightstown	USA New Jersey	McGuire AFB
KABQ	ABQ	Albuquerque	USA New Mexico	Albuquerque Intl Sunport
KBUF	BUF	Buffalo	USA New York	Buffalo-Niagara Intl
KJFK	JFK	New York	USA New York	Kennedy Intl
KSWF	SWF	Newburgh	USA New York	Stewart Intl
KIAG	IAG	Niagara Falls	USA New York	Niagara Falls Intl
KCVG	CVG	Cincinnati	USA Ohio	Cincinnati / Northern Kentucky Intl
KCLE	CLE	Cleveland	USA Ohio	Hopkins Intl
KLCK	LCK	Columbus	USA Ohio	Rickenbacker Intl
KTOL	TOL	Toledo	USA Ohio	Toledo Express
KOKC	OKC	Oklahoma City	USA Oklahoma	Will Rogers World
KPDX	PDX	Portland	USA Oregon	Portland Intl
KPHL	PHL	Philadelphia	USA Pennsylvania	Philadelphia Intl
KPIT	PIT	Pittsburgh	USA Pennsylvania	Pittsburgh Intl
KCHS	CHS	Charleston	USA South Carolina	Charleston AFB - Intl
KMEM	MEM	Memphis	USA Tennessee	Memphis Intl
KAMA	AMA	Amarillo	USA Texas	Amarillo Intl
KDAL	DAL	Dallas	USA Texas	Dallas Love
KDFW	DFW	Dallas Fort Worth	USA Texas	Dallas Fort Worth Intl
KELP	ELP	El Paso	USA Texas	El Paso Intl
KIAH	IAH	Houston	USA Texas	George Bush Intercontinental / Houston
KMAF	MAF	Midland	USA Texas	Midland Intl
KSAT	SAT	San Antonio	USA Texas	San Antonio Intl
KNGU	NGU	Norfolk	USA Virginia	Norfolk NAS
KORF	ORF	Norfolk	USA Virginia	Norfolk Intl
KPAE	PAE	Everett	USA Washington	Snohomish Co.
KBFI	BFI	Seattle	USA Washington	Boeing Field / King Co. Intl
KSEA	SEA	Seattle	USA Washington	Seattle - Tacoma Intl
KMKE	MKE	Milwaukee	USA Wisconsin	Gen. Mitchell Intl
KPSM	PSM	Portsmouth	USA, New Hampshire	Pease Intl Tradeport
UTTT	TAS	Tashkent	Uzbekistan	Yuzhny
NVVV	VLI	Port Vila	Vanuatu	Bauerfield
SVMI	CCS	Maiquetia - Caracas	Venezuela	Simon Bolivar Intl
SVMC	MAR	Maracaibo	Venezuela	La Chinita Intl
NSFA	APW	Apia	Western Samoa	Faleolo Intl
FLLS	LUN	Lusaka	Zambia	Lusaka Intl
FVHA	HRE	Harare	Zimbabwe	Harare Intl

SORTED BY AIRPORT NAME

ICAO	IATA	City	Country	Airport
OMAA	AUH	Abu Dhabi	U.A.E.	Abu Dhabi Intl
YPAD	ADL	Adelaide	Australia South Australia	Adelaide Intl
SBCT	CWB	Curitiba	Brazil	Afonso Pena Intl
VAAH	AMD	Ahmedabad	India	Ahmedabad
OMAL	AAN	Al Ain	U.A.E.	Al Ain Intl
MROC	SJO	San Jose	Costa Rica	Alajuela (Juan Santamaria Intl)
KABQ	ABQ	Albuquerque	USA New Mexico	Albuquerque Intl Sunport
EGAA	BFS	Belfast	United Kingdom	Aldergrove
SKCL	CLO	Cali	Columbia	Alfonso Bonilla Aragon Intl
YBAL	ASP	Alice Springs	Australia Northern Territory	Alice Springs
UAAA	ALA	Almaty	Kazakhstan	Almaty
KAMA	AMA	Amarillo	USA Texas	Amarillo Intl
GVAC	SID	Sal	Cape Verdi	Amilcar Cabral
PANC	ANC	Anchorage	USA Alaska	Anchorage Intl
ESSA	ARN	Stockholm	Sweden	Arlanda
SCEL	SCL	Santiago	Chile	Arturo Merino Benitez Intl
SGAS	ASU	Asuncion	Paraguay	Asuncion / Silvio Pettrossi Intl
HESN	ASW	Aswan	Egypt	Aswan
LTBA	IST	Istanbul	Turkey	Ataturk
LGAT	ATH	Athens	Greece	Athens
NZAA	AKL	Auckland	New Zealand	Auckland Intl
YMAV	AVV	Avalon	Australia Victoria	Avalon
OBBI	BAH	Bahrain	Bahrain	Bahrain Intl
ZGGG	CAN	Guangzhou	Peoples Republic of China	Baiyun
KBWI	BWI	Baltimore	USA Maryland	Baltimor Washington Intl
VCBI	CMB	Colombo	Sri Lanka	Bandaranaike Intl
VOBG	BLR	Bangalore	India	Bangalore
VTBD	BKK	Bangkok	Thailand	Bangkok Intl
KBGR	BGR	Bangor	USA Maine	Bangor Intl
GBYD	BJL	Banjul	Gambia	Banjul Intl
LEMD	MAD	Madrid	Spain	Barajas
LFSB	BSL	Basle-Mulhouse	France	Basle-Mulhouse
NVVV	VLI	Port Vila	Vanuatu	Bauerfield
LLBG	TLV	Tel Aviv	Isreal	Ben Gurion
TXKF	BDA	Bermuda	Bermuda Islands	Bermuda Intl
EKBI	BLL	Billund	Denmark	Billund
ZBTJ	TSN	Tianjin	Peoples Republic of China	Binhai
EGBB	BHX	Birmingham	United Kingdom	Birmingham
KBHM	BHM	Birmingham	USA Alabama	Birmingham Intl
LFBO	TLS	Toulouse	France	Blagnac
FABL	BFN	Bloemfontein	South African Rep	Bloemfontein
KBFI	BFI	Seattle	USA Washington	Boeing Field / King Co. Intl
LIPE	BLQ	Bologna	Italy	Borgo Panigale
UKBB	KBP	Kyiv	Ukraine	Boryspil
KBDL	BDL	Windsor Locks	USA Connecticut	Bradley Intl
YBBN	BNE	Brisbane	Australia Queensland	Brisbane Intl
EBBR	BRU	Brussels	Belgium	Brussels Natl
KBUF	BUF	Buffalo	USA New York	Buffalo-Niagara Intl
YBCS	CNS	Cairns	Australia Queensland	Cairns Intl
HECA	CAI	Cairo	Egypt	Cairo Intl
CYYC	YYC	Calgary	Canada Alberta	Calgary Intl
FACT	CPT	Cape Town	South African Rep	Cape Town Intl
ZBAA	PEK	Beijing	Peoples Republic of China	Capital
SUMU	MVD	Montevideo	Uruguay	Carrasco Intl. / Gen Cesareo L. Berisso
LIMF	TRN	Torino	Italy	Caselle
SCFA	ANF	Antofagasta	Chile	Cerro Moreno Intl
WSSS	SIN	Singapore	Singapore	Changi
LFPG	CDG	Paris	France	Charles de Gaulle
KCHS	CHS	Charleston	USA South Carolina	Charleston AFB - Intl
RKPC	CJU	Cheju	Korea	Cheju Intl
VOMM	MAA	Chennai	India	Chennai Intl

SORTED BY AIRPORT NAME

ICAO	IATA	City	Country	Airport
VABB	BOM	Mumbai	India	Chhatrapati Shivaji Intl
RCTP	TPE	Taipei	Taiwan	Chiang Kai Shek Intl
VTCC	CNX	Chiang Mai	Thailand	Chiang Mai Intl
RJCJ	OKD	Sapporo	Japan	Chitose
NZCH	CHC	Christchurch	New Zealand	Christchurch Intl
CYYQ	YYQ	Churchill	Canada Manatoba	Churchill
LIRA	CIA	Rome	Italy	Ciampino
KCVG	CVG	Cincinnati	USA Ohio	Cincinnati / Northern Kentucky Intl
RPLC	CRK	Angeles - Clark	Philippines	Clark Intl.
LSGG	GVA	Geneva	Switzerland	Cointrin
PACD	CDB	Cold Bay	USA Alaska	Cold Bay
EDDK	CGN	Cologne-Bonn	Germany	Cologne-Bonn
KDFW	DFW	Dallas Fort Worth	USA Texas	Dallas Fort Worth Intl
KDAL	DAL	Dallas	USA Texas	Dallas Love
OSDI	DAM	Damascus	Syria	Damascus Intl
HTDA	DAR	Dar-Es-Salaam	Tanzania	Dar-Es-Salaam Intl
YPDN	DRW	Darwin	Australia Northern Territory	Darwin Intl
KDEN	DEN	Denver	USA Colorado	Denver Intl
LFLX	CHR	Chateauroux	France	Deols
SBSV	SSA	Salvador	Brazil	Dep. L.E. Magal'haes Intl
KDTW	DTW	Detroit	USA Michigan	Detroit Metro Wayne County
LGRP	RHO	Rhodos	Greece	Diagoras
OTBD	DOH	Doha	Qatar	Doha Intl
MMGL	GDL	Guadalajara	Mexico	Don Miguel Hidalgo Intl
FKKD	DLA	Douala	Cameroon	Douala
KDOV	DOV	Dover	USA Delaware	Dover AFB
OMDB	DXB	Dubai	U.A.E.	Dubai Intl
EIDW	DUB	Dublin	Ireland	Dublin Intl
KDLH	DLH	Duluth	USA Minnesota	Duluth Intl
FADN	DUR	Durban	South African Rep	Durban Intl
EDDL	DUS	Dusseldorf	Germany	Dusseldorf
PASY	SYA	Shemya	USA Alaska	Eareckson AS
CYEG	YEG	Edmonton	Canada Alberta	Edmonton Intl
SBEG	MAO	Manaus	Brazil	Eduardo Gomes Intl
PAEI	EIL	Fairbanks	USA Alaska	Eielson AFB
KELP	ELP	El Paso	USA Texas	El Paso Intl
SAME	MDZ	Mendoza	Argentina	El Plumerillo
LEBL	BCN	Barcelona	Spain	El Prat
MSLP	SAL	San Salvador	El Salvador	El Salvador Intl
SKBO	BOG	Santafe De Bogota	Columbia	Eldorado Intl
PAED	EDF	Anchorage	USA Alaska	Elmendorf AFB
SEMT	MEC	Manta	Equador	Eloy Alfaro Intl
KOMA	OMA	Omaha	USA Nebraska	Eppley
SKBQ	BAQ	Barranquilla	Columbia	Ernesto Cortissoz
LTAC	ESB	Ankara	Turkey	Esenboga
SAEZ	EZE	Buenos Aires	Argentina	Ezeiza Intl. - Ministro Pistarini
PAFA	FAI	Fairbanks	USA Alaska	Fairbanks Intl
NSFA	APW	Apia	Western Samoa	Faleolo Intl
DIAP	ABJ	Abidjan	Ivory Coast	Felix Ho'uphouet-Boigny
LIRF	FCO	Rome	Italy	Fiumicino
ENBR	BGO	Bergen	Norway	Flesland
LEVT	VIT	Vitoria	Spain	Foronda
LPPR	OPO	Porto	Portugal	Francisco' Sa Carneiro
EDDF	FRA	Frankfurt / Main	Germany	Frankfurt / Main
MYGF	FPO	Freeport	Bahamas	Freeport Intl
KFAT	FAT	Fresno	USA California	Fresno Yosemite Intl
NFTF	TBU	Nuku'alofa	Tonga	Fua'amotu Intl
OMFJ	FJR	Fujairah	UAE	Fujairah Intl
RJFF	FUK	Fukuoka	Japan	Fukuoka
SBGL	GIG	Rio De Janeiro	Brazil	Galeao Antonio Carlos Jobin Intl
CYQX	YQX	Gander	Canada Newfoundland	Gander Intl

SORTED BY AIRPORT NAME

ICAO	IATA	City	Country	Airport
ENGM	GEN	Oslo	Norway	Gardermoen
EGKK	LGW	London-Gatwick	United Kingdom	Gatwick
MMAA	ACA	Acapulco	Mexico	Gen Juan N. Alvarez Intl
KMKE	MKE	Milwaukee	USA Wisconsin	Gen. Mitchell Intl
KIAH	IAH	Houston	USA Texas	George Bush Intercontinental / Houston
EGPF	GLA	Glasgow	United Kingdom	Glasgow
SASJ	JUJ	Jujuy	Argentina	Gobernador Horacio Guzman
CYYR	YYR	Goose Bay	Canada Newfoundland	Goose
GCLP	LPA	Gran Canaria	Canary Island	Gran Canaria
TBPB	BGI	Barbados, Bridgetown	British West Indies	Grantley Adams Intl
MUGM	NBW	Guantanamo Bay	Cuba	Guantanamo Bay NAS
SGES	AGT	Ciudad del Este	Paraguay	Guarani Intl
SBRF	REC	Recife	Brazil	Guararapes Intl
EDFH	HHN	Hahn	Germany	Hahn
RJCH	HKD	Hakodate	Japan	Hakodate
CYHZ	YHZ	Halifax	Canada Nova Scotia	Halifax Intl
WIIIH	HLP	Jakarta-Halim	Indonesia	Halim Intl
EDDH	HAM	Hamburg	Germany	Hamburg
EDDV	HAJ	Hannover	Germany	Hannover
FVHA	HRE	Harare	Zimbabwe	Harare Intl
TNCC	CUR	Curacao Island	Netherland Antilles	Hato Intl
EGLL	LHR	London-Heathrow	United Kingdom	Heathrow
PHTO	ITO	Hilo	USA Hawaii	Hilo Intl
KFLL	FLL	Fort Lauderdale	USA Florida	Hollywood Intl
VHHH	HKG	Hong Kong	Peoples Republic of China	Hong Kong Intl
ZSSS	SHA	Shanghai	Peoples Republic of China	Hongqiao
PHNL	HNL	Honolulu	USA Hawaii	Honolulu Intl
KCLE	CLE	Cleveland	USA Ohio	Hopkins Intl
MPHO	HOW	Balboa	Panama	Howard AFB
ZGSZ	SZX	Shenzhen	Peoples Republic of China	Huangtian
KHSV	HSV	Huntsville	USA Alabama	Huntsville Intl. - Jones
KIND	IND	Indianapolis	USA Indiana	Indianapolis Intl
VIDP	DEL	Delhi	India	Indira Gandhi Intl
SACO	COR	Cordoba	Argentina	Ing. A. L. V. Taravella Intl
RJOI	IWA	Iwakuni	Japan	Iwakuni MCAS
SMJP	PBM	Zandery	Suriname	J. A. Pengel Intl
KJAX	JAX	Jacksonville	USA Florida	Jacksonville Intl
ZSHC	HGH	Hangzhou	Peoples Republic of China	Jianqiao
FAJS	JNB	Johannesburg	South African Rep	Johannesburg Intl
HKJK	NBO	Nairobi	Kenya	Jomo Kenyatta
SPIM	LIM	Lima-Callao	Peru	Jorge Chavez Intl
SKRG	MDE	Rionegro	Columbia	Jose Maria Cordova
WRSJ	SUB	Surabaya	Indonesia	Juanda
RODN	DNA	Okinawa Island	Japan	Kadena AB
RJFK	KOJ	Kagoshima	Japan	Kagoshima
PHJR		Kapolei	USA Hawaii	Kalaeloa
BGSF	SFJ	Sondre Stromfjord	Greenland	Kangerlussuaq
RJBB	KIX	Osaka	Japan	Kansai Intl
KMCI	MCI	Kansas City	USA Missouri	Kansas City Intl
RCKH	KHH	Kaohsiung	Taiwan	Kaohsiung Intl
EKCH	CPH	Copenhagen,	Denmark	Kastrup
BIKF	KEF	Keflavik	Iceland	Keflavik
KJFK	JFK	New York	USA New York	Kennedy Intl
UHHH	KHV	Khabarovsk	Russia	Khabarovsk Novy
HTKJ	JRO	Kilimanjaro	Tanzania	Kilimanjaro Intl
RKSS	SEL	Seoul	Korea	Kimpo Intl
OEDR	DHA	Dhahran	Saudi Arabia	King Abdulaziz AB
OEJN	JED	Jeddah	Saudi Arabia	King Abdulaziz Intl
OEDF	DMM	Dammam	Saudi Arabia	King Fahd Intl
OERK	RUH	Riyadh	Saudi Arabia	King Khalid Intl
YSSY	SYD	Sydney	Australia NewSouthWales	Kingford Smith Intl

SORTED BY AIRPORT NAME

ICAO	IATA	City	Country	Airport
UHWV	VVO	Vladivostok	Russia	Knevichi
WBKK	BKI	Kota Kinabalu	Malaysia	Kota Kinabalu
DGAA	ACC	Accra	Ghana	Kotoka Intl
WMKK	KUL	Kuala Lumpur	Malaysia	Kuala Lumpur Intl - Sepang
WBGG	KCH	Kuching	Malaysia	Kuching Intl
RKJK	KUV	Kunsan	Korea	Kunsan AB
OKBK	KWI	Kuwait	Kuwait	Kuwait Intl
MGGT	GUA	Guatemala City	Guatemala	La Aurora Intl
SVMC	MAR	Maracaibo	Venezuela	La Chinita Intl
OPLA	LHE	Lahore	Pakistan	Lahore Intl
KSTL	STL	Saint Louis	USA Missouri	Lambert - Saint Louis Intl
ESGG	GOT	Goteborg	Sweden	Landvetter
LCLK	LCA	Larnaca	Cyprus	Larnaca Intl
MDSD	SDQ	Santo Domingo	Dominican Republic	Las Americas Intl
GOOY	DKR	Dakar	Senegal	Leopold Sedar Senghor
MMMX	MEX	Mexico City	Mexico	Lic Benito Juarez Intl
EBLG	LGG	Liege	Belgium	Liege
FWLI	LLW	Lilongwe	Malawi	Lilongwe Intl
LOWL	LNZ	Linz	Austria	Linz
LPPT	LIS	Lisbon	Portugal	Lisbon
UGGG	TBS	Tbilisi	Georgia	Lochini
KBOS	BOS	Boston	USA Massachusetts	Logan Intl
KLAX	LAX	Los Angeles	USA California	Los Angeles Intl
GCXO	TFN	Tenerife North	Canary Island	Los Rodeos
KSDF	SDF	Louisville	USA Kentucky	Louisville Intl - Standiford
TJSJ	SJU	San Juan	Puerto Rico	Luis Munoz Marin Intl
FLLS	LUN	Lusaka	Zambia	Lusaka Intl
ELLX	LUX	Luxembourg	Luxembourg	Luxembourg
HELX	LXR	Luxor	Egypt	Luxor
EHBK	MST	Maastricht	Netherlands	Maastricht-Aachen
VMMC	MFM	Macau	Macau	Macau Intl
FAMM	MBD	Mafikeng	South African Rep	Mafikeng Intl
LGTS	SKG	Thessaloniki	Greece	Makedonia
DNKN	KAN	Kano	Nigeria	Mallam Aminu Kano
LIMC	MPX	Milan	Italy	Malpensa
EGCC	MAN	Manchester	United Kingdom	Manchester
SEQU	UIO	Quito	Ecuador	Mariscal Sucre Intl
LFML	MRS	Marseille / Provence	France	Marseille / Provence
KLAS	LAS	Las Vegas	USA Nevada	McCarran Intl
KIAB	IAB	Wichita	USA Kansas	McConnell AFB
KWRI	WRI	Wrightstown	USA New Jersey	McGuire AFB
YMML	MEL	Melbourne	Australia Victoria	Melbourne Intl
KMEM	MEM	Memphis	USA Tennessee	Memphis Intl
KOAK	OAK	Oakland	USA California	Metro Oakland Intl
KMIA	MIA	Miami	USA Florida	Miami Intl
KMAF	MAF	Midland	USA Texas	Midland Intl
KMSP	MSP	Minneapolis	USA Minnesota	Minneapolis-St Paul Intl
UMMS	MSQ	Minsk	Belarus	Minsk-2
RJSM	MSJ	Misawa	Japan	Misawa AB
KBFM	BFM	Mobile	USA Alabama	Mobile Downtown
HKMO	MBA	Mombasa	Kenya	Moi
CYUL	YUL	Montreal (Dorval)	Canada Quebec	Montreal Intl (Dorval)
CYMX	YMX	Montreal (Mirabel)	Canada Quebec	Montreal Intl (Mirabel)
EDDM	MUC	Munich	Germany	Munich
DNMM	LOS	Lagos	Nigeria	Murtala Muhammed
NFFN	NAN	Nadi	Fiji Islands	Nadi Intl
RJFU	NGS	Nagasaki	Japan	Nagasaki
RJNN	NGO	Nagoya	Japan	Nagoya
ROAH	OKA	Naha, Okinawa	Japan	Naha
RJAA	NRT	Tokyo Narita	Japan	Narita (New Tokyo Intl)
MYNN	NAS	Nassau	Bahamas	Nassau Intl

SORTED BY AIRPORT NAME

ICAO	IATA	City	Country	Airport
OPNH	WNS	Nawabshah	Pakistan	Nawabshah
VECC	CCU	Calcutta	India	Netaji Subhas Chandra Bose Intl
RJCC	CTS	Sapporo	Japan	New Chitose
KMSY	MSY	New Orleans	USA Louisiana	New Orleans Intl
KEWR	EWR	Newark	USA New Jersey	Newark Intl
KIAG	IAG	Niagara Falls	USA New York	Niagara Falls Intl
LFMN	NCE	Nice / Cote D'Azur	France	Nice / Cote D'Azur
RPLL	MNL	Manila	Philippines	Ninoy Aquino Intl
KORF	ORF	Norfolk	USA Virginia	Norfolk Intl
KNGU	NGU	Norfolk	USA Virginia	Norfolk NAS
GQNN	NKC	Nouakchott	Mauritania	Nouakchott
KORD	ORD	Chicago	USA Illinois	O'Hare Intl
KONT	ONT	Ontario	USA California	Ontario Intl
KMCO	MCO	Orlando	USA Florida	Orlando Intl
LFPO	ORY	Paris	France	Orly
RJOO	ITM	Osaka	Japan	Osaka Intl
RKSO	OSN	Osan	Korea	Osan AB
EBOS	OST	Ostend	Belgium	Ostend
CYOW	YOW	Ottawa	Canada Ontario	Ottawa / MacDonald-Cartier Intl
NSTU	PPG	Pago Pago	American Samoa	Pago Pago Intl
KPMD	PMD	Palmdale	USA California	Palmdale AF Plant 42
WSAP	QPG	Singapore	Singapore	Paya Lebar Aero
KPSM	PSM	Portsmouth	USA, New Hampshire	Pease Intl Tradeport
WMKP	PEN	Penang Island	Malaysia	Penang Intl
YPPH	PER	Perth	Australia Western Aust.	Perth Intl
KPHL	PHL	Philadelphia	USA Pennsylvania	Philadelphia Intl
KPHX	PHX	Phoenix	USA Arizona	Phoenix Sky Harbor Intl
VTSP	HKT	Phuket	Thailand	Phuket Intl
TTPP	POS	Port of Spain	Trinidad	Piarco Intl
KMZJ	MZJ	Marana	USA Arizona	Pinal Air Park
SPSO	PIO	Pisco	Peru	Pisco
KPIT	PIT	Pittsburgh	USA Pennsylvania	Pittsburgh Intl
WIMM	MES	Medan	Indonesia	Polonia
DNPO	PHC	Port Harcourt	Nigeria	Port Harcourt
KPDX	PDX	Portland	USA Oregon	Portland Intl
SBBR	BSB	Brasilia	Brazil	Pres Juscelino Kubitschek Intl
EGPK	PIK	Prestwick	United Kingdom	Prestwick
OEMA	MED	Madinah	Saudi Arabia	Prince Mohammad Bin Abdulaziz Intl
ZSPD	PVG	Shanghai	Peoples Republic of China	Pudong
ULLI	LED	Saint Petersburg	Russia	Pulkovo
OPKC	KHI	Karachi	Pakistan	Quaid-E-Azam Intl
OJAI	AMM	Amman	Jordan	Queen Alia Intl
ETAR	RMS	Ramstein	Germany	Ramstein AB
OMRK	RKT	Ras Al Khaimah	U.A.E.	Ras Al Khaimah Intl
GCTS	TFS	Tenerife South	Canary Island	Reina Sofia
CYRB	YRB	Resolute Bay	Canada North West Terr.	Resolute Bay
KLCK	LCK	Columbus	USA Ohio	Rickenbacker Intl
OERY		Riyadh	Saudi Arabia	Riyadh AB
SPQU	AQP	Arequipa	Peru	Rodriguez Ballon
SAAR	ROS	Rosario	Argentina	Rosario
LERT	RTA	Rota	Spain	Rota Navy
SBPA	POA	Porto Alegre	Brazil	Salgado Filho Intl
KSAT	SAT	San Antonio	USA Texas	San Antonio Intl
KSAN	SAN	San Diego	USA California	San Diego Intl - Lindbergh
KSFO	SFO	San Fransciso	USA California	San Fransciso Intl
LIRP	PSA	Pisa	Italy	San Giusto
LEZL	SVQ	Seville	Spain	San Pablo
SBSN	STM	Santarem	Brazil	Santarem Intl
SBGR	GRU	Sao Paulo	Brazil	Sao Paulo / Intl - Guarulhos
KSAV	SAV	Savannah	USA Georgia	Savannah Intl
EHAM	AMS	Amsterdam	Netherlands	Schiphol

SORTED BY AIRPORT NAME

ICAO	IATA	City	Country	Airport
LOWW	VIE	Vienna	Austria	Schwechat
KSEA	SEA	Seattle	USA Washington	Seattle - Tacoma Intl
OOMS	MCT	Muscat	Oman	Seeb Intl
RJSS	SDJ	Sendai	Japan	Sendai
LIMJ	GOA	Genoa	Italy	Sestri
EINN	SNN	Shannon	Ireland	Shannon
OMSJ	SHJ	Sharjah	U.A.E	Sharjah Intl
UUEE	SVO	Moscow	Russia	Sheremetyevo
LICZ	NSY	Catania	Italy	Signonella AB
SEGU	GYE	Guayaquil	Ecuador	Simon Bolivar Intl
SVMI	CCS	Maiquetia - Caracas	Venezuela	Simon Bolivar Intl
FBSK	GBE	Gaborone	Botswana	Sir Seretse Khama Intl
LWSK	SKP	Skopje	Macedonia	Skopje
KPAE	PAE	Everett	USA Washington	Snohomish Co.
WIII	CGK	Jakarta	Indonesia	Soekarno-Hatta Intl
UHMM	GDX	Magadan	Russia	Sokol
ENZV	SVG	Stavanger	Norway	Sola
KVCV	VCV	Victorville	USA California	Southern California Intl
CYYT	YYT	Saint Johns	Canada Newfoundland	St. Johns Intl
EGSS	STN	London-Stansted	United Kingdom	Stansted
CYJT	YJT	Stephenville	Canada Newfoundland	Stephenville
KSWF	SWF	Newburgh	USA New York	Stewart Intl
ESMS	MMX	Malmo	Sweden	Sturup
EDDS	STR	Stuttgart	Germany	Stuttgart
RPLB	SFS	Subic Bay	Philippines	Subic Bay Intl
WMSA	SZB	Kuala Lumpur (old airport)	Malaysia	Sultan Abdul Aziz Shah-Subang Intl
WMKJ	JHB	Johar Bahru	Malaysia	Sultan Ismail
RCSS	TSA	Taipei	Taiwan	Sungshan
KTPA	TPA	Tampa	USA Florida	Tampa Intl
SBCF	CNF	Belo Horizonte	Brazil	Tancredo Neves Intl
SGCO		Concepcion	Paraguay	Ter. Crl. Carmelo Peralta
KATL	ATL	Atlanta	USA Georgia	The Hartsfield Atlanta Intl
BGTL	THU	Thule	Greenland	Thule AB
MPTO	PTY	Panama City	Panama	Tocumen Intl
DXXX	LFW	Lome	Togo	Tokoin
RJTT	HND	Tokyo Haneda	Japan	Tokyo Intl
KTOL	TOL	Toledo	USA Ohio	Toledo Express
NWWW	NOU	Noumea	New Caledonia	Tontouta
CYYZ	YYZ	Toronto	Canada Ontario	Toronto / Pearson Intl
LETO	TOJ	Madrid	Spain	Torrejon
KTUS	TUS	Tucson	USA Arizona	Tucson Intl
EFTU	TKU	Turku	Finland	Turku
VTBU	UTP	Rayong	Thailand	U-Taphao Intl
SBBE	BEL	Belem	Brazil	Val De Caes
CYVR	YVR	Vancouver	Canada British Columbia	Vancouver Intl
EFHK	HEL	Helsinki	Finland	Vantaa
SBKP	VCP	Campinas	Brazil	Viracopos Intl
SLVR	VVI	Santa Cruz	Bolivia	Viru Viru Intl
KIAD	IAD	Washington D.C.	USA D. C.	Washington Dulles Intl
KICT	ICT	Wichita	USA Kansas	Wichita Mid - Continent
KOKC	OKC	Oklahoma City	USA Oklahoma	Will Rogers World
KYIP	YIP	Detroit	USA Michigan	Willow Run
CYWG	YWG	Winnipeg	Canada Manatoba	Winnipeg Intl
UHPP	PCK	Petropavlovsk Kamchatsky	Russia	Yelizovo
RJTY	OKO	Tokyo Yokota	Japan	Yokota AB
UTTT	TAS	Tashkent	Uzbekistan	Yuzhny
ZYTL	DLC	Dalian	Peoples Republic of China	Zhoushuizi
VGZR	DAC	Dhaka	Bangladesh	Zia Intl
LSZH	ZRH	Zurich	Switzerland	Zurich